

□ | {app-image}

Changelog BETA-Test

Table of Contents

Major changes to FENECON Online Monitoring — E-Mobility	2
Flat widgets become chips.	3
Mobile View	3
Desktop View.	4
Main Window — Charging Station	5
Other chips in the charging station	8
FEMS Cockpit	11
1. Production	12
2. Consumption	14
3. Storage System	17
4. Grid	20
5. Weather	22
6. FENA	23
Favorites	23
System status	25
History of Your Energy Journey	26
FEMS AppCenter	27
Autarky	28
Self-consumption	28
Analysis of Battery Expansion	29
BETA test video	33
BETA Test & Next-Level EV Charging	33
Update history	33
03.09.2026 — Automatic Phase Switching	33
21.07.2026 — ASKOMA & my-PV — New Timetable Visualization	34
13.07.2026 — Negative electricity market prices with FEMS App Grid-	
Optimized Charging — EEG 2025	36
16.06.2026 — Optimization of FEMS App Grid-Optimized Charging	37
Migration of Widgets	37

Major changes to FENECON Online Monitoring — E-Mobility

Weather Widget in the Cockpit.	37
Peak Shaving — Symmetric and Asymmetric.	38
Relay Control.	38
12.05.2026 — Migration: System-on-a-Chip	38
Time-of-use Tariffs: Energy Scheduler v2	39
28.04.2026 — Migration: New Tabs in the Tree Navigation	39
Time-of-Use Tariff	39
Grid-Optimized Charging.	40
Manual Charging & Discharging.	42
14.04.2026 — Production Chip: Forecast	42
Migration of the "myPV" and "ASKOMA" Widgets	43
31.03.2026 — Implementation: MENNEKES Charging Station	43
Schedule: Weekly Review.	44
Migration of the FEMS App Heat Pump Widget	44
24.03.2026 — Chip: Production	45
23.03.2026 — Schedule Improvements	45
03.03.2026 — Desktop: Chips as a menu tree	46
Display — Charging power in watts	47
24.02.2026 — Bug fixes	47
17.02.2026 — KEBA P30 Implementation	47
03.02.2026 — App Center Vehicles — Generic Vehicle	48
Chip: Vehicle App Center	48
27.01.2026 — Implementation of Hardy Barth's cPμ2 Charging Station	49
New Chip: Help	49
16.12.2025 — Switching FEMS App AC Charging Station to BETA	50
New Chips: Schedule and Charging Mode	50
New Charging Mode: Minimum Charging with Surplus PV Power	51
01.12.2025 — Phase Switching	51

Major changes to FENECON Online Monitoring — E-Mobility

Dear Customer,

Thank you very much for your interest in participating in our BETA test.

The following guide explains the basic changes to FENECON Online Monitoring.

Further down on this page, you'll find a changelog that explains the new features added at regular intervals.

Flat widgets become chips

- In this approach, flat widgets are replaced by chips that can be tapped or clicked to create a menu structure.
- The main window on your screen displays the contents of the selected chip.
- In addition to viewing relevant information about your system, you can also configure settings in the main window.
- Depending on the chip you select, you will receive new chips until you reach the endpoint of the menu or menu branch.
- You can use the breadcrumb menu to navigate back, either step by step or directly to the start of your FENECON Online Monitoring (house icon).



To improve the user-friendliness of our applications, we take a "mobile-first" approach to development.

- The user interface is not yet the final version; it is still under development. As a result, changes may occur in the layout of the chips and the overall design.

Mobile View

Flat widgets become chips



Mobile View	Explanation
	Swipe up from the bottom to open the main chip menu. • The standard tabs <i>History</i>, <i>Autarky</i>, <i>Self-Consumption</i>, <i>Grid</i>, and <i>Consumption</i> are displayed here, as well as • Specific chips for each FEMS App, in this case: two KEBA P40 wall boxes.
	You can navigate back using the breadcrumbs displayed at the top of the chip menu.

Table 1. Mobile View

Desktop View


Desktop View	Explanation
	The chips are located in the side menu in a tree-style navigation
	The breadcrumbs are located at the top of your screen.

Table 2. Desktop View

Main Window — Charging Station


	Click or tap to activate the chip for your wallbox.
--	---

Table 3. Main Window — Charging Station Chip

Depending on the selected chip, the main window displays different information and settings:



Grundmodus
Aktiver Modus
Status
Energie seit Ladebeginn

Aus
Aus
EV nicht verbunden
0 Wh

Nächste Aufgaben

Thu Jan 15 03:00 - Thu Jan 15 07:00

Schnell

Fri Jan 16 03:00 - Fri Jan 16 07:00

Schnell

Sat Jan 17 03:00 - Sat Jan 17 07:00

Schnell

Main Window — Charging Station

In this case, you'll see the main window of the charging station, which displays custom tasks (schedule) at the bottom.

It also displays which modes are currently active: **Base Mode** and **Active Mode**.



	Settings for Base Mode can be configured via the <i>Charging Mode</i> chip.
	Settings for Active Mode can be configured via the <i>Schedule</i> chip.

Table 4. Explanation — Base Mode and Active Mode



The charging modes have been renamed. The functions behind them are similar, but not identical.

Click on the *Charging Mode* tab to open the following main window, where you can set the **Base mode**:

In welchen Modus soll beladen werden

- ☒ Keine Beladung
- ☐ Minimal Beladung mit PV-Überschuss
- ☐ PV-Überschuss
- ☐ Schnellladen

Image 1. Overview — Charging Modes

No charging

Completely disables the charging station.

Minimum Charging with PV Surplus

The *Minimal Charging with PV Surplus* mode guarantees that the vehicle is charged to the minimum level. If there is sufficient PV surplus, it is used. If there is no PV surplus, the vehicle is charged using grid withdrawal up to the minimum charging power.

PV surplus

In *PV surplus* mode (formerly: Automatic), the EV's charging is dynamically adjusted to the excess electrical energy (e. g., PV surplus). In addition, the *Phase Switching* chip allows you to switch between 1-phase and 3-phase charging.

Fast Charging

In *Fast Charging* mode (formerly: manual), the vehicle charges as quickly as possible—depending on whether the phase switching setting is set to 3-phase or 1-phase. If there is sufficient excess PV power, it is used and combined with grid withdrawal.

Click the *Schedule* tab to open the following main window, where you can set an **Active Mode**:

Main Window — Charging Station




Image 2. Overview — Schedule

This main window displays your custom tasks (schedule). If you already have a task in the list, you can *EDIT* it to, e. g. adjust the time period or the charging mode during that time period.

Click [DELETE] to remove the task.

Use [**ACCEPT**] to save your changes to the task.



Image 3. Overview — Created Tasks

Tap the + *Add Task* button to create a new task.

You will be taken to the following main window:




Image 4. Main Window — Add New Task

Here you can set the **Start**, the **End**, the **Repetition Interval** (currently: daily), and the desired **Charging Mode**.

Pressing [**+ ADD**] saves the task and displays it in the overview.




If no tasks are scheduled, **Active Mode** is the same as **Base Mode**.

Other chips in the charging station

By activating the charging station chip, you'll receive additional chips:

The main window of this chip displays the forecast for your wallbox:



Main Window — Charging Station





	There is a slider for this in the corresponding main window. • Energy limit 0: The vehicle will continue to charge without restriction until its battery is fully charged or the charging mode is set to <i>Off</i>. • Energy limit 20: The battery is charged up to a maximum of 20 kWh during each charging cycle. etc.
	Activating this chip takes you to Manual Phase Switching.
	This takes you directly to the settings for the connected vehicle Generic Vehicle.
	Further down in the side menu is the <i>Help</i> chip: 1. View the beta test changelog links to this documentation. 2. By clicking Participate in the beta test survey, you can provide us with feedback: Share feedback on the BETA test.
	

Table 5. Explanation — Additional chips in the charging station



- With the transition to the BETA test, Multi-Charging-Point Management is no longer required.
- It is also no longer automatically installed when more than one charging point is installed.
- A feature for prioritizing charging points will be implemented at a later date.

FEMS Cockpit

The FEMS Cockpit is the central user interface for FEMS. Here, you can view all relevant information about your system:




Image 5. Cockpit — Main Window — Explanation

- Zentrales Element ist der **Leistungsmonitor**. Er zeigt die aktuelle Produktion, den Verbrauch, die Be- und Entladung der Batterie sowie den derzeitigen Netzbezug oder die Netzeinspeisung.
- The gray bars represent the maximum possible power of the various elements, which is generated automatically.
- The consumption is calculated.
- If one of the elements (except consumption) does not exist in the system, it is hidden.

Clicking or tapping on the respective icons will take you to the corresponding subpages of your system's standard main menu items:

1. [Production](#)
2. [Consumption](#)
3. [Storage System](#)
4. [Grid](#)
5. [Weather](#)
6. [FENA](#)

Selbstverständlich können Sie auch die das Hauptmenü links verwenden, um zu den gewünschten Seiten zu navigieren.

1. Production




Image 6. Main Menu Item — Production — Main Window

Der Hauptmenüpunkt *Erzeugung* zeigt in seinem Hauptfenster die aktuelle Leistung Ihrer Erzeuger, z. B. der PV-Anlage, an. Sie erhalten außerdem eine Erzeugungsprognose für den aktuellen und den kommenden Tag in kWh angezeigt, sowie im unteren Bereich Details über Ihre eingebundenen Erzeuger.

The production forecast, shown as a dashed line in the graph, becomes visible after installing the free [FEMS App Weather](#).

Other submenu items include:

Phase-accurate production:

PRODUCTION		
All Systems		
Cockpit	Total	27,589 W
Production	30.0 kWp SolarEdge 30k	12,943 W
Phase-accurate	Phase L1	242 V 17.0 A 4,314 W
	Phase L2	239 V 17.0 A 4,314 W
	Phase L3	238 V 17.0 A 4,314 W
History		
Info	Total DC	14,646 W
Consumption	19.8 kWp MPPT 1	722 V 10.1 A 7,317 W
Storage System		
Grid	11.2 kWp MPPT 2	564 V 8.2 A 4,631 W
Weather	11.2 kWp MPPT 3	567 V 4.9 A 2,752 W
Favorites	For technical reasons, the sum of the individual phases can slightly deviate from the total sum.	

Image 7. Main Menu Item — Production — Phase-Accurate

History:




Image 8. Main Menu Item — Production — History

Phase-Accurate History:

Total, Phase L1, Phase L2, Phase L3




Image 9. Main Menu Item — Production — Phase-Accurate History

History of the individual MPP trackers:

2. Consumption




Image 10. Main Menu Item — Production — History of Individual MPP Trackers

Current & Voltage of the Individual MPP Trackers:

Current, Voltage




Image 11. Main Menu Item — Production — Current & Voltage of Individual MPP Trackers

2. Consumption



Image 12. Main Menu Item — Consumption — Main Window

Der Hauptmenüpunkt *Verbrauch* zeigt in seinem Hauptfenster die aktuelle Leistung des Verbrauchs an. Sie erhalten außerdem eine Verbrauchsprognose für den aktuellen und den kommenden Tag in kWh angezeigt, sowie im unteren Bereich Details über einzelne eingebundene Verbraucher.

The consumption forecast, shown as a dashed line in the graph, is one of the features of the new app design.

Other submenu items include:

Phase-accurate:

2. Consumption



Image 13. Main Menu Item — Consumption — Phase-Accurate View

History:

All data for the connected consumer loads is displayed here.





Image 14. Main Menu Item — Consumption — History

If desired, these can be shown or hidden individually by clicking on the corresponding graph descriptions in the legend.

Phase-Accurate History:

Total, Phase L1, Phase L2, Phase L3



3. Storage System

The main window of the *Storage System* menu item displays the current power and state of charge (SoC) of the battery system.

Charging, Discharging, State of Charge

The dashed graphs on this page each show forecast values.

The forecast values displayed in this way help you better estimate future trends in storage capacity and state of charge.

The forecast values are calculated as accurately as possible, taking into account any scheduled times as well.



The sudden activation of a consumer load can affect the forecast values in the short term.

3. Storage System




Image 16. Main Menu Item — Storage System — Main Window

Directly below the main menu item *Storage System*, you will find the available operating modes for the battery system; in this case:

- Time-of-Use Tariff (with Tibber as the provider)
- Grid-Optimized Charging
- Manual Charging & Discharging

Possible operating modes include *Static* or *Time-of-Use Tariff*, *Grid-Optimized Charging*, *Manual Charging & Discharging*, and *Modbus/TCP Write Access*. These are explained in the corresponding FEMS App manual.



Example — Time-of-Use Tariff:

How is the operating mode determined?

An artificial intelligence system links the available forecasts with dynamic electricity prices and determines an optimized energy plan. This plan defines the appropriate operating mode for every quarter-hour of the available time period.

The system also provides a *phase-accurate view*:




Image 17. Main Menu Item — Storage System — Phase-Accurate

A History:

Charging, Discharging, State of Charge (SoC, dashed line)




Image 18. Main Menu Item — Storage System — History

As well as a "Settings" page where the emergency power reserve is configured.




Image 19. Main Menu Item — Storage System — Settings

4. Grid



Here, you prepare the system for an upcoming capacity expansion with additional battery modules, for which the battery energy storage system must be brought to 30 % SoC.

Expansion of the energy storage system



These settings are available only for the *INSTALLER* access level.

After clicking the  slider labeled **Capacity Expansion**, you can schedule the capacity expansion for a specific day and time, ...




Image 20. Main Menu Item — Storage System — Scheduled Expansion

... or to start the necessary preparations right away:




Image 21. Main Menu Item — Storage System — Immediate Expansion

4. Grid



Image 22. Main Menu Item — Grid — Main Window

The main window of the *Grid* menu item displays the current power fed into the grid as well as the grid withdrawal, and in the graph below, the current electricity price.

The details at the bottom indicate whether grid feed-in is currently being limited by an external factor, and how much power was fed into each phase.

Another submenu item is *History*:




Image 23. Main Menu Item — Grid — History

It offers two additional graphical representations: *Phase-accuracy* and *Current & Voltage*.

Phase-accurate:

Total, Phase L1, Phase L2, Phase L3

5. Weather




Image 24. Main Menu Item — Grid — History — Phase-accurate

Current & Voltage:

Current L1, Current L2, Current L3, Voltage L1, Voltage L2, Voltage L3




Image 25. Main Menu Item — Grid — History — Current & Voltage

If desired, you can show or hide individual phases by clicking on the corresponding entries in the legend.

5. Weather




Image 26. Main Menu Item — Weather — Main Window

The *Weather* main menu item displays the weather at the system location in its main window, provided you have installed the [FEMS App Weather](#) app.

You'll also receive a weather forecast for today and for the coming days.

6. FENA



FENA stands for FENECON Assistant and is a smart assistant that helps you optimize your energy management and provides you with helpful information. Currently, FENA provides information and forecasts, e. g. *Emergency power active: Your FENECON system is currently supplying power to your consumer loads from your storage*. Additional features will be added at a later date.

Favorites

Nutzer mit dem Zugriffslevel *OWNER* haben die Möglichkeit, Menüpunkte als Favoriten festzulegen. Diese werden dann im Hauptmenü unter *Favoriten* angezeigt.

Hauptpunkte wie Erzeugung, Verbrauch, Netz usw., aber auch eingebundene Komponenten wie eine Ladestation können als Favoriten festgelegt werden. Auch bestimmte Unter-Seiten wie *Historie* können einzeln favorisiert werden, werden jedoch als "anhängig" von der Hauptseite betrachtet: Wird der Menüpunkt favorisiert, werden die darunterliegenden Menüpunkte ebenfalls favorisiert.

Favorites

1. By default, **Overall History of Your Energy Journey** is set as a favorite. The following section explains how to set additional favorites.




Image 27. Favorites — Default Page

2. Navigate to the desired page in the FENECON app. In this example, go to a KEBA wallbox, which can be found under the main menu item *Consumption*.
3. Activate the heart icon to add the page to Favorites:



Image 28. Add to Favorites

4. The page now appears in the navigation bar under *Favorites*.
5. To remove the page from your favorites, activate the heart icon again. The page will then no longer appear in the navigation bar under *Favorites*.




Image 29. Main menu item — Favorites — Main window with Favorites

System status

The system status display is located in the upper-right corner of the cockpit. Clicking the  takes you to an overview of all system components and their statuses:

EVERYTHING IS OK 

System state		
	Total state	
	Meter	
	Haus (4,1 Nord) [GoodWe] charger0 GoodWe Charger PV1	
	Haus (2,5 Süd) [GoodWe] charger1 GoodWe Charger PV2	
	Ariana ctrlBrainsSingle0 (Component is not active!)	
	Brains OS Controller Single	
	Heizung Büro ctrlHeatingRoom0 Controller Heating Room	
	Heizung Küche ctrlHeatingRoom1 Controller Heating Room	
	Heizung Wohnzimmer ctrlHeatingRoom2 Controller Heating Room	

Continue your Energy Journey and expand your system—e. g. with additional storage capacity, heating elements, heat pumps, wall boxes, and the corresponding FEMS Apps. You'll get an overview of your Energy Journey so far, and you'll also see the next steps for expanding your system in a meaningful way.

History of Your Energy Journey

The *History* submenu item displays graphical data for your system regarding:

Production, Charging, Discharging, Grid feed-in, Purchased from grid, Consumption, State of Charge (SoC, dashed line)

You can choose between the time periods *Day*, *Week*, *Month*, *Year*, and *Total Period*. You can also display a custom (different) time period. The values are displayed in kWh.




Image 30. History — Daily View

Clicking or tapping on the respective value in the legend hides or shows the corresponding graph.




Image 31. History — Monthly View

In the monthly and annual views, the State of Charge (SoC) of is replaced by Direct Consumption .

Select *Export* under the History menu item to export the values for the selected time period as an Excel file (.xlsx). By default, the file is located in your device's Downloads folder. The file name includes the FEMS number and the time period for which the values were exported.




Image 32. History — Export

FEMS AppCenter

The AppCenter for registering, redeeming, and managing license keys can be found in the main menu under *Your Energy Journey*:




Image 33. Hauptmenüpunkt Energy Journey — FEMS AppCenter im Untermenü

You will then see the AppCenter in the main window:




Image 34. FEMS AppCenter — Hauptfenster

From there, you can continue with the [AppCenter features](#).

Autarky

This main menu item is part of the Energy Journey and displays your self-sufficiency rate as a percentage. The autarky rate describes the proportion of your total energy consumption that is met by your own self-consumption. The higher the autarky rate, the less dependent you are on external energy sources.




Image 35. Main Menu Item — Autarky — Main Window

You can also view an Autarky history. Here, you can choose between *Day*, *Week*, *Month*, *Year*, and the *Total Period*. You can also view a custom (different) time period.




Image 36. Main Menu Item — Autarky — History

Self-consumption

Self-consumption indicates the percentage of the power currently being produced that is consumed for direct consumption and for battery charging.




Image 37. Main Menu Item — Self-Consumption — Main Window

Self-consumption also has a *historical view*:




Image 38. Main Menu Item — Self-Consumption — History



If there was no production, there can be no self-consumption! Therefore, self-consumption is only shown in the chart if there was also production at that time.

Analysis of Battery Expansion

The battery expansion analysis shows you how expanding your battery system would affect your energy self-sufficiency. You'll receive step-by-step instructions and visualizations to help you find the optimal system configuration for your needs.

1. Start the analysis by clicking [VIEW ANALYSIS].

Analysis of Battery Expansion

Take a relaxed approach to the changes in the energy world.
With us, you are ideally prepared for your 100 % energy transition.

Use our Energy Journey platform to analyse and calculate how you can sensibly develop
your system further and which extensions you can benefit from.



Battery extension: is it worth it?

Whether it is worth retrofitting your energy storage system depends on various factors. Your system has been in operation for more than a year. Analyse here what effect a battery extension would have had

VIEW ANALYSIS

Image 39. Main Menu Item — Battery Extension Analysis — Start

2. Enter your current electricity price in cents per kWh. If you have a time-of-use tariff, enter the average rate. Click the [START ANALYSIS].


Energy Journey: Battery extension

Whether it is worth retrofitting your energy storage system depends on various factors. Your system has been in operation for more than a year. Analyse here what effect a battery extension would have had

Please enter your current electricity price. If you are already using a time-of-use-tariff, please enter an average value.

Cent/
kWh

41

START ANALYSIS

Image 40. Main Menu Item — Battery Expansion Analysis — Step 2

3. You will first receive information for the past year.



Your data

Last year's details on your current FENECON Home:

Battery modules	30
Charging and discharging capacity	30 kW
Grid supply	2,817 kWh
Electricity price	41 ct/kWh

 EDIT

Image 41. Main Menu Item — Battery Expansion Analysis — Step 3

- 4. The bar chart below shows how many kWh you could have saved during this period with the corresponding battery upgrade.

Analysis of Battery Expansion




Image 42. Main Menu Item — Battery Expansion Analysis — Step 4

Number of modules	+ 15	+ 18	+ 22	+ 26	+ 30
Savings on electricity consumption in euros*	119.72	123.16	126.11	126.11	126.11
Charging and discharging capacity of the storage in kW:** (Total)	+ 0.00 (= 30 kW)	- 3.12 (= 26.88 kW)	- 0.88 (= 29.12 kW)	+ 0.00 (= 30 kW)	+ 0.00 (= 30 kW)
Increase in total usable capacity in kWh: (Total)	+ 42.00 (= 126 kWh)	+ 50.40 (= 134.4 kWh)	+ 61.60 (= 145.6 kWh)	+ 72.80 (= 156.8 kWh)	+ 84.00 (= 168 kWh)

* Potential annual savings in euros that would have resulted from a battery extension
Calculation: Your current electricity price multiplied by the electricity savings in kWh per module.

** The charging and discharging power (kW) as well as the emergency power capacity of your storage increases to this value. Detailed information on the values that can be processed on the AC side and the achievable output depending on the number of modules can be found in the [product data sheet Home 30](#)

Disclaimer
The calculations in the analysis are based on your information on the electricity price, the grid purchases and the grid feed-in data of your storage system in the past year. These underlying parameters can change at any time. The calculations are therefore only examples that serve as an orientation for the possible profitability of a battery extension and do not guarantee that financial savings can actually be achieved. This does not constitute a guarantee on the part of FENECON.

Image 43. Main Menu Item — Battery Expansion Analysis — Step 5

BETA test video

BETA Test & Next-Level EV Charging

```
<iframe width="950" height="534" src="https://www.youtube-nocookie.com/embed/e83Hfu9aV1c"
loading="lazy" referrerpolicy="strict-origin-when-cross-origin" allow="accelerometer;
autoplay; clipboard-write; encrypted-media; gyroscope; picture-in-picture; web-share"
allowfullscreen></iframe>
```

[Open video on YouTube](#) 


''' <<<

Update history

03.09.2026 — Automatic Phase Switching

In addition to [manual phase switching](#) (1- or 3-phase), BETA participants now have the option of automatic phase switching:

**PV Überschuss -
Ladeleistung in kW**



Mit wie vielen Phasen soll das Fahrzeug beladen werden?

☐  **1-phasig**

☐  **3-phasig**

☐  **Automatische Phasenumschaltung**

Die automatische Phasenumschaltung setzt voraus, dass sowohl das Fahrzeug als auch der Ladepunkt diese Funktion technisch unterstützen. Der Vorgang des Phasenwechsels kann wenige Minuten dauern, in denen das Fahrzeug nicht lädt.

The phases are automatically switched based on the charging power. This allows even a small amount of excess PV power to be utilized.



- The *Fast Charge* mode always uses 3 phases.
- Your vehicle must support dynamic phase switching.



- The switching times depend on the wallbox and its internal logic.
- The phase switching may take a few minutes.


21.07.2026 — ASKOMA & my-PV — New Timetable Visualization

The heating element integrations for ASKOMA and my-PV now feature new visualizations in the schedule, as shown here using ASKOMA as an example:


You can access the visualization via the **ASKOMA chip** in the **side menu** of Online Monitoring:




The ASKOMA main window then displays the status, the current heating output, and the current mode (e. g. PV surplus):



Forecast



History



Schedule

In the main window of the Schedule Chip, you can set the **Active Mode** of the heating element, which differs from the base mode:

< Zeitplan

Heizmodus	Schnell heizen ▼
Wiederholung	Täglich ▼
Start	Wähle Zeit
Ende	Wähle Zeit
+ ÜBERNEHMEN	

1. First, select the desired temporary heating mode, e. g. **Quick Heat**.
2. Then select the recurrence, e. g. **Daily**.

3. Finally, set the **Start** and **End** times using the selection dials:



You can scroll through the hours and minutes on the computer using the mouse wheel.

4. + *APPLY* the settings.

The heating element **settings** have also been given a new visual design:



- ☐ **Schnell heizen**
Der Askoma-Heizstab versucht, mit der maximal möglichen Heizstufe auf die maximal eingestellte Temperatur zu heizen. Die maximale Leistungsdauer beträgt 10 h. Nach dieser Zeit macht der Heizstab eine Stunde Pause.
- ☒ **PV-Überschuss**
Die Aktivierung erfolgt automatisch, perfekt angepasst an die überschüssige und verfügbare PV-Energie.
- ☐ **Keine Beheizung**

Here, you can set the **Base mode** for your heating element.

13.07.2026 — Negative electricity market prices with FEMS App Grid-Optimized Charging — EEG 2025

- The app is available for download **in Germany**.
- The app can be found in the new "Feed-in tariffs" category in the App Center.

- The download is free.



Energy Scheduler V2 must be running for the installation.



The "EEG 2025" app is available for installation by owners who are already participating in the BETA test. Currently, this requires an existing installation of the FEMS App Time-of-Use Tariff app.

After installing the "EEG 2025" app, the zero remuneration for negative electricity prices on the exchange is taken into account in the energy schedule for Grid-Optimized Charging.

16.06.2026 — Optimization of FEMS App Grid-Optimized Charging

The FEMS App Grid-Optimized Charging has been optimized for negative electricity market prices (EEG 2025).


The "EEG 2025" App was developed for this purpose.

The app will be available for free at a later date.

Migration of Widgets

Weather Widget in the Cockpit

Currently available only in the desktop version, the weather widget now has a visualization in the Online Monitoring Cockpit:




Peak Shaving — Symmetric and Asymmetric

Relay Control

12.05.2026 — Migration: System-on-a-Chip

The following widgets, which were previously moved to the tree navigation in the side menu, are now listed under *Storage System*:

- Grid-Optimized Charging
- Time-of-Use Tariff
- Manual Charging & Discharging



The following chips have been **newly added**:

- Autarky
- Self-consumption
- Weather Forecast (if installed)
- Heating element
- Askoma Heating Element
- Threshold Control



With a few exceptions, all widgets have been moved to the tree navigation as chips.

Time-of-use Tariffs: Energy Scheduler v2

- The field test is already using the new "Energy Scheduler v2."

In addition, thanks to a report from the community, an error in the processing of negative electricity prices was fixed.

28.04.2026 — Migration: New Tabs in the Tree Navigation

The *Time-of-Use Tariff*, *Grid-Optimized Charging*, and *Manual Charging/Discharging* chips have been integrated into the tree navigation. The main window of each chip allows you to control the respective functions and, if available, view the history.

Time-of-Use Tariff

The *Time-of-Use Tariff* widget as a chip in the tree navigation:

Alle Systeme

Einstellungen

 Energiemonitor

 Historie

 Netz

▼

 Erzeugung

▼

 Verbrauch

▼

 Wallbox KONA D (rechts)

▼

 Wallbox KONA S (links)

▼

 Manuelle Be-/Entladung

▼

 Netzdienliche Beladung

▼

 **Dynamischer Stromtarif**

▲

 Historie

Einstellungen

Grid-Optimized Charging

A simple click or tap on the chip opens its main window, which displays, among other things, the current purchase price and information *about your current schedule*.




More information about the schedule will be provided at a later date.

Click or tap *History* to view the history of the time-of-use tariff in the main window. As usual, you can use the blue buttons above the graph to select the desired date or time period.


Under *Settings*, you can set the option to *OFF* to disable optimization based on a time-of-use tariff. Your system will then operate in Self-Consumption Optimization mode; prices will continue to be recorded.

Select *AUTOMATIC* to enable automatic optimization. If desired, the *Active Charging from the Grid* function can be enabled via a toggle switch.



Grid-Optimized Charging


The *Grid-Optimized Charging* widget as a chip in the tree navigation:



Click or tap *History* to view the charging history in the main window:

Scroll or swipe down to view the grid-friendly charging history:

Via *Settings*, you can enable or disable Manual Charging & Discharging and set the power level:



Manual Charging & Discharging



Manual Charging & Discharging

The *Manual Charging/Discharging* widget as a chip in the tree navigation:




This widget is currently available to users who had already installed the *Manual Charging/Discharging* feature before switching to the BETA app. We are currently working on making it available to all users.

In *Settings*, you can enable or disable Manual Charging & Discharging and set the power level:



14.04.2026 — Production Chip: Forecast

The main window now displays a forecast of production as a dashed line on the graph:




Migration of the "myPV" and "ASKOMA" Widgets

The widgets for the two power-to-heat apps have now been implemented as chips.


31.03.2026 — Implementation: MENNEKES Charging Station

For participants in the BETA field test, the *Mennekes Charging Station* tile has been available in the side menu of the tree navigation since the FEMS version 2026.3.3, released on 31.03.2026:



You can also select the charging mode for the MENNEKES Charging Station:

Schedule: Weekly Review




Schedule: Weekly Review

The schedule for the MENNEKES Charging Station now also supports the *Weekly Recurrence* option:



Migration of the FEMS App Heat Pump Widget

The FEMS App Heat Pump has been integrated into the tree navigation as a chip. The chip's main window allows you to control the heat pump:



24.03.2026 — Chip: Production

The *Production* widget can now be found as a chip in the side menu within the tree navigation:

Alle Systeme

Einstellungen

Energiemonitor

Historie

Netz

Erzeugung

Phasengenau

Historie

Verbrauch

When you activate the chip, the following main window will appear:

/ Erzeugung / **Phasengenau**

Erzeugung

Gesamt

4.941 W

Gesamt AC

4.322 W

Phase L1

1.441 W

Phase L2

1.439 W

Phase L3

1.441 W

Carport (8,8 Nord)

982 W

Phase L1

236 V 1,4 A 328 W

Phase L2

235 V 1,4 A 326 W

Phase L3

236 V 1,4 A 328 W

Haus (2,5 Nord + 12,1 Süd)

3.340 W

Phase L1

233 V 4,0 A 1.113 W

Phase L2

233 V 4,0 A 1.113 W

Phase L3

234 V 4,0 A 1.113 W

Gesamt DC

619 W

Haus (4,1 Nord) [GoodWe]

434 V 0,3 A 130 W

Haus (2,5 Süd) [GoodWe]

272 V 1,8 A 489 W

Die Summe der einzelnen Phasen kann aus technischen Gründen geringfügig von der Gesamtsumme abweichen.

23.03.2026 — Schedule Improvements

In the Vehicle App Center, you can now specify the battery capacity under "Generic Vehicle." This helps improve the Schedule:

Generisches Fahrzeug

Alias

KONA S (links)

Minimale Leistung bei einphasigem Laden

1380
Watt

Maximale Leistung bei einphasigem Laden

7360
Watt

Minimale Leistung bei dreiphasigem Laden

4140
Watt

Maximale Leistung bei dreiphasigem Laden

11040
Watt

0, wenn dreiphasiges Laden nicht unterstützt ist

Batteriekapazität

50000
Wh

Unterstützt dieses EV das Unterbrechen eines Ladevorgangs?

☒


APP AKTUALISIEREN

APP ENTFERNEN


03.03.2026 — Desktop: Chips as a menu tree

In the desktop version, widgets and chips are now displayed in the side menu as part of a tree-style navigation:

Previous layout



New layout




The layout of the mobile version remains unchanged.

You can now access other main views via the side menu without using the breadcrumbs.

Display — Charging power in watts

In the main view of your wallbox, the current charging power in watts is now displayed under *Power*:



24.02.2026 — Bug fixes

- 1. Troubleshooting Phase Detection.
- 2. General Troubleshooting for [Switching to the BETA app](#)
- 3. **Bug fix** After uninstalling the wallbox, the installation key remains associated with FEMS.

17.02.2026 — KEBA P30 Implementation

Owners of a KEBA P30 charging station can now participate in the beta test and use the new features of the FEMS App beta.



03.02.2026 — App Center Vehicles — Generic Vehicle

In addition, improvements were made to [Switching from the regular app to the beta app and back](#).

03.02.2026 — App Center Vehicles — Generic Vehicle

Generic Vehicle is automatically installed when you [switch to the BETA app](#).

"Generic Vehicle" means:

- the **primary vehicle** that is charged by default at this charging station.
- It is recommended that you specify the correct model name of the vehicle.

The following settings are available for the connected, Generic Vehicle:

Generisches Fahrzeug

Alias

KONA D (rechts)

Minimale Leistung bei einphasigem Laden [W]

1380

Maximale Leistung bei einphasigem Laden [W]

7360

Minimale Leistung bei dreiphasigem Laden [W]

4140

Maximale Leistung bei dreiphasigem Laden [W]

11040

0, wenn dreiphasiges Laden nicht unterstützt ist

Unterstützt dieses EV das Unterbrechen eines Ladevorgangs?

APP AKTUALISIEREN

APP ENTFERNEN

After you have made the desired settings, save them by clicking the [UPDATE APP] button.

Chip: Vehicle App Center

The *Vehicle App Center* chip in the Charging Station Chip menu now provides access to the settings for the Generic Vehicle.

/ Wallbox KONA S (links) / App Center Fahrzeuge

Generisches Fahrzeug

Alias

KONA D (rechts)

Minimale Leistung bei einphasigem Laden [W]

1380

Maximale Leistung bei einphasigem Laden [W]

7360

Minimale Leistung bei dreiphasigem Laden [W]

4140

Maximale Leistung bei dreiphasigem Laden [W]

11040

0, wenn dreiphasiges Laden nicht unterstützt ist

Unterstützt dieses EV das Unterbrechen eines Ladevorgangs?


APP AKTUALISIEREN

APP ENTFERNEN


27.01.2026 — Implementation of Hardy Barth's cPμ2 Charging Station

Owners of a Hardy Barth cPμ2 charging station can now participate in the BETA test and use the new features of the FEMS App BETA.

After following the instructions at [Switching in the FEMS App configuration](#), the corresponding chips will be available in your side menu:




When you activate the chip, the following main window will appear:



Currently, the Hardy Barth cPμ2 charging station [all features](#) offers the same functions as the KEBA P40 wallbox, with the exception of phase switching.


New Chip: Help

Right from the start, the new *Help* chip is now available in the FENECON Online Monitoring's side menu:



When you activate the chip, the following main window will appear:

16.12.2025 — Switching FEMS App AC Charging Station to BETA




The link leads to [this documentation](https://docs.fenecon.de/redirect/fenecon/de/beta_change_log).

16.12.2025 — Switching FEMS App AC Charging Station to BETA

Here's how to switch to the FEMS App BETA:

1. Start in the FEMS App Center.
2. Navigate to your FEMS App installation: e. g. *KEBA KeContact P40* or *eCharge Hardy Barth Charging Station*.
3. Click on the honeycomb icon and then on *EDIT APP*.
4. You will now see the following window:



5. Slide the slider to participate in the BETA test.



To shift back, follow the same procedure.

New Chips: Schedule and Charging Mode

- Two new chips are available for controlling the wallbox: [Schedule and Charging Mode](#).
- The wallbox's main window has been redesigned to display these new settings.

• ---


New Charging Mode: Minimum Charging with Surplus PV Power

- The **Minimum Charging with PV Surplus** mode guarantees a minimum level of charging for the vehicle. If there is sufficient PV surplus, it is used. If there is no PV surplus, the vehicle is charged using grid withdrawal up to the minimum charging power.

01.12.2025 — Phase Switching

If the "PV" mode is selected on your charging station, you can manually switch from 1-phase to 3-phase charging using the *Phase Switching* chip:

Tap or click the chip to access the following main view:



Use case

One scenario would be to use the limited PV production to charge the vehicle anyway by manually switching to single-phase charging.

Switching during charging:

When manually switching from single-phase to three-phase and vice versa, the hardware undergoes a 30-second switchover process each time.



- Please wait while this switch is in progress.
- During these 30 seconds, the charging power is reduced to 0 kW, and then the switchover occurs.



- When switching phases, vehicles behave differently depending on the model.

- Your vehicle must support phase shifting.