




FEMS App my-PV

Version:2026.9.2

Table of Contents

1. Introduction	2
2. Installation of the FEMS App my-PV	2
2.1. IP address of the my-PV product.	2
2.2. Settings in the my-PV Cloud.	3
3. How to use the FEMS App my-PV	3
3.1. my-PV functionality	4
3.1.1. my-PV Main Window	4
3.1.2. History	4
3.1.3. Task scheduling	5
3.1.4. Settings	6
4. Contact us	7

1. Introduction



1. Introduction

Dear customer,

Thank you for choosing the "FEMS App my-PV". You are welcome to send us your suggestions so that we can further improve the quality of our products.


2. Installation of the FEMS App my-PV

- Use these instructions to grant FEMS write access to my-PV products.
- For general instructions on how to install a FEMS App, cf. [AppCenter documentation](#).
- Launch the FENECON App.

	In the AppCenter, select FEMS App my-PV.
	1. The name of the heating element can be specified as an Alias, e. g. AC•Thor domestic hot water storage tank. 2. Enter the IP address of the my-PV product in the IP Address field. This can be determined as described here. 3. You must also specify the maximum power rating of the heating element, e. g. 3000 W for the AC•Thor. Complete the installation by clicking [INSTALL APP].


2.1. IP address of the my-PV product

1. Find the IP address of your router's web interface, provided that the router is on the same network as the my-PV product.
2. Alternatively, you can find the IP address using the my-PV Cloud:

	Under Settings → IP Settings → Current IP Address .
---	--


2.2. Settings in the my-PV Cloud

In addition, the IP address of the FEMS must be entered in the my-PV Cloud so that the my-PV product can be controlled by the FEMS.

	In the my-PV Cloud, navigate to Settings and then to Control Settings. 1. For the <i>Control Type</i>, select Modbus TCP. 2. Enter the IP address of FEMS. Save the settings.
---	--

The connection to FEMS has now been established.

3. How to use the FEMS App my-PV

Once the installation is complete, the FEMS App my-PV my-PV will be available in the side menu of the FENECON app (shown here: desktop view):	
---	--

3.1. my-PV functionality

3.1. my-PV functionality

3.1.1. my-PV Main Window

If you click or tap directly on **my-PV** in the side menu, the main window will display the current water temperature, the historical trend (4 hours), and the future trend (20 hours) of the water temperature in a graph. The heating output is also displayed.



3.1.2. History

Select **History** from the side menu, and the main window will display the historical data for your heating element (water temperature/heating output).




If you use a temperature sensor, its data will also be displayed in the history.



Using **[ADD]**, you can create tasks that override the **Base Mode** of the heating element according to your preferences and within the specified limits:

Set the desired **Heating Mode**, its repeat interval, and the start and end times.

Click [**+ ACCEPT**] to save the settings and save the task.



The task is now visible in the main window under **Schedule**:

3.1. my-PV functionality

Heating mode No heating

Start	06:30
End	09:00
Repeat	Daily

EDIT

+ ADD

The assignment can be edited or deleted at any time.

3.1.4. Settings

In the side menu, the bottom item is **Settings**. Here, you can set the **Base Mode** for the heating element, which is active outside the time periods defined by the **Schedule**:

my-PV



☐
Fast heat

The Askoma heating rod automatically selects the equivalent heating level. The maximum power duration is 10 hours. After that, it makes 1h pause.

☒
PV surplus

Enables even heating of different buffer tanks. Activation happens automatically, perfectly adapted to your excess and available PV energy.

☐
No heating

Description of the **Base Modes**:

Fast heat

The heating element operates at full power to heat the water as quickly as possible. This setting is particularly useful, e. g. when combined with Time-of-Use tariffs during periods of low electricity prices.

PV surplus

In this mode, the PV system's excess production—which would otherwise be subject to grid feed-in—is used for heating.

No heating

The heating element is inactive.

4. Contact us

For support, please contact:

FENECON GmbH
Gewerbepark 6
94547 Iggensbach

Phone — Service: +49 (0) 9903 6280 0

E-mail — Service: service@fenecon.de