

FENECON

FENECON Industrial XL Operating Instructions

Item no.: IXL 010 | Item no.: IXL 0100

V2 - 2025.11.11

Table of Contents

1. Information on these installation and service instructions	5
1.1. Manufacturer	5
1.2. Formal information on installation and service instructions	5
1.3. Version/revision of the installation and service instructions	5
1.4. Symbol conventions	7
1.5. Structure of warning notices	8
1.6. Terms and abbreviations	9
1.7. Availability.....	10
1.8. Serial number.....	10
1.9. Type label	10
1.9.1. Position of the type label on the container	11
2. Safety	12
2.1. Intended use	12
2.2. Field of application	12
2.3. Qualification of staff	12
2.3.1. Trained electricians	13
2.3.2. Service personnel	13
2.4. Safety and protective devices	13
2.4.1. Earthing connections/potential equalization	13
2.4.2. Lightning protection	14
2.4.3. Fire alarm system.....	14
2.4.4. Connection to fire alarm control panel (FACP)	14
2.4.5. Faults in the fire detection system	17
2.4.6. Maintenance of the fire detection system.....	17
2.5. Residual risks	18
2.6. Safety instructions.....	19
2.6.1. General information on the electrical energy storage system	19
2.6.2. Installation, operation and maintenance.....	20
2.6.3. Fire protection	21
2.7. Behavior in emergency situations.....	21
2.8. Reasonably foreseeable misuse	23
2.9. Pictograms	24
2.10. Operating materials/equipment	25
2.10.1. Electrolyte solution of the battery packs	25
2.10.2. Agent of the cooling system.....	26

Table of Contents

2.10.3. Electrical equipment	26
2.11. Notes on occupational health and safety	27
2.12. Personal protective equipment.....	28
2.13. Spare and wear parts	28
2.14. IT security	28
3. Technical data	29
3.1. General	29
3.2. System overview	30
3.2.1. Physical overview.....	30
3.2.2. Block diagram.....	31
3.2.3. Network plan	32
3.3. Battery container.....	33
3.3.1. Steel construction — Battery containers	34
3.3.2. Control cabinet.....	35
3.3.3. AC connection area	36
3.3.4. DC connection area.....	37
3.3.5. Feedthroughs	39
3.3.6. Battery tower	43
3.3.7. Battery	44
3.3.8. Cooling system distribution	45
3.3.9. Fire alarm system (FAS).....	46
3.3.10. Lightning protection system	49
3.4. Inverter rack.....	50
3.4.1. Steel construction — Inverter rack	51
3.4.2. Inverter	52
3.4.3. Cable ladder	53
3.5. Cooling system.....	56
3.6. Cable bridges	58
4. Installation preparation	59
4.1. General description.....	59
4.2. Scope of delivery	60
4.3. Tools/machines required	60
5. Assembly — General	62
5.1. Select installation site	63
5.2. Assembly steps	64
5.2.1. Unloading the container.....	64

5.2.2. Unloading the inverter racks	64
5.2.3. Unloading the liquid cooling system.	64
5.2.4. Install equipotential bonding/earthing.....	65
5.2.5. Wiring the AC/DC connections.....	65
6. Network connection	65
6.1. Standard setup — Internet via fiber optics	65
6.2. Internet via ETH	66
6.3. General information	66
7. Initial commissioning	68
8. FEMS — FENECON Energy Management System	69
8.1. Technical documentation — FEMS	69
8.2. Online Monitoring	70
8.3. Access data.....	70
8.4. Overview	70
9. Troubleshooting	71
9.1. FEMS Online Monitoring.....	71
9.1.1. Fault display	71
9.1.2. Troubleshooting.....	72
9.2. FENECON Service.....	73
9.2.1. Details for the FENECON Service.....	73
9.2.2. Service times.....	73
10. Technical maintenance	74
10.1. Tests and inspections	74
10.2. Cleaning	74
10.3. Maintenance work.....	75
10.4. Repairs	75
11. Storage	76
11.1. Commissioning instructions — Room air conditioning	76
11.1.1. General	76
11.1.2. Installation site.....	77
11.1.3. Electrical connection.....	78
12. Utilization load	80
13. Transport	81
13.1. Safety instructions.....	81
13.2. Change of location	82

Table of Contents

13.3. Transportation process	82
14. Dismantling and disposal	85
14.1. Safety instructions.....	85
14.2. Prerequisites	85
14.3. Disposal.....	86
15. Declaration of Conformity	87
16. Register	89
16.1. Applicable documents	89
16.2. List of Images.....	91
16.3. List of Tables	93

1. Information on these installation and service instructions

These installation and service instructions are an integral part of the electrical energy storage system and must be kept in its immediate vicinity and accessible to personnel at all times. Furthermore, all documents listed in the appendix to these installation and service instructions and the operating instructions of the component manufacturers must be observed (link to [Applicable documents](#)).

Personnel must have carefully read and understood these installation and service instructions before starting any work.



Ensure that the latest version of the installation and service instructions is always used.



In this manual, the product is described as an electrical energy storage system, storage system or system. These terms refer to the battery energy storage system (BESS) supplied.

1.1. Manufacturer

FENECON GmbH
Gewerbepark 6
94547 Iggensbach
GERMANY

Phone: +49 (0) 9903 6280 0
Fax: +49 (0) 9903 6280 909
E-Mail: aftersales.industrial@fenecon.de
Website: www.fenecon.de

1.2. Formal information on installation and service instructions

© FENECON GmbH, 2025
All rights reserved.
Reprinting, even in part, is only permitted with the permission of FENECON GmbH.

1.3. Version/revision of the installation and service instructions

Version/revision	Changes to installation and service instructions	Date	Name
V0	First draft	27/08/2025	FENECON GmbH

1.3. Version/revision of the installation and service instructions

Version/revision	Changes to installation and service instructions	Date	Name
V1	Release	01/09/2025	FENECON GmbH
V1	Publication on docs.fenecon.de	10.2025	FENECON PM
V2	Revision	11.2025	FENECON PM Industrial

Table 1. Version/revision

1.4. Symbol conventions

Representation	Meaning
"Highlighting"	Highlighting special terms in the text
[push-button]	Operating and display element (e. g. push-button, signal light)
>>button<<	button and visualization (e. g. push-button, signal light)
	Reference to sections/chapters of these instructions or to Applicable documents (section Technical data)

Table 2. Symbol conventions

	This signal word indicates an imminent danger. If this danger is not avoided, it will result in death or serious injury.
	This signal word indicates a possible danger. If this danger is not avoided, it can lead to death or serious injury.
	This signal word indicates a potentially dangerous situation. If this dangerous situation is not avoided, it may result in minor or moderate injury.
	This signal word indicates actions to prevent damage to property. Observing these instructions prevents damage to or destruction of the system.
	Supplementary information

Table 3. Symbol conventions — Signal words

1.5. Structure of warning notices

1.5. Structure of warning notices

Warning notices protect against possible personal injury and damage to property if observed and classify the magnitude of the danger by means of the signal word.

Warnings are structured according to the SAFE method:

Signal word	Meaning
S	Signal word (DANGER, WARNING, CAUTION or NOTICE)
A	Type and source of danger Description of the hazard and the cause of the hazard
F	Consequence Description of the possible consequences for humans, animals and the environment that may result from the hazard
E	Escape Recommendations on how hazards can be avoided

Table 4. SAFE method



Source of the danger

Possible consequences of non-compliance.

- Measures to avoid/prohibit.

1.6. Terms and abbreviations

The following terms and abbreviations are used in the installation and service instructions:

Term/Abbreviation	Meaning
AC	Alternating Current
ADR	Accord européen relatif au transport international des marchandises dangereuses par route (European Agreement concerning the International Carriage of Dangerous Goods by Road)
BMS	Battery Management System
FACP	Fire alarm control panel
CMB	Current Measurement Board
CSC	Cell Supervisor Circuit
DC	Direct Current
EMS	Energy Management System
FEMS	FENECON Energy Management System
CX	commissioning
MCB	Circuit breaker
GCP	grid connection point (GCP)
NC	Normally Closed (NC) — normally closed/ normally closed contact
NMC	Nickel-Manganese-Cobalt
PE	Protective conductor
PV	Photovoltaic
RCD	Residual Current Device
RTE	Round-Trip-Efficiency — System efficiency Ratio of discharged to charged energy.
SoC	State of Charge — State of Charge The available capacity in a battery, expressed as a percentage of the nominal capacity.
VDE	German Association for Electrical, Electronic & Information Technologies e. V.
Widget	Component of Online Monitoring

Table 5. Terms and abbreviations

1.7. Availability

1.7. Availability

The operator must keep these installation and service instructions or relevant parts of them within easy reach in the immediate vicinity of the product.

Technical changes, images and information in these installation and service instructions are subject to change without prior notice.

If the product is handed over to another person, the operator passes these installation and service instructions on to that person.

1.8. Serial number

Each electrical energy storage unit is marked with a unique serial number.


This consists of two parts:

- the product number ("IXL010" for a system with FENECON batteries or "IXL0100" for a storage system with order integration)
- a consecutive, six-digit numerical code (e. g. 000001)


The serial number is located on the type label and is used to uniquely identify the electrical energy storage system. It also provides information on the development status.

Changes in the development status that lead to deviations in operation or maintenance are indicated in these installation and service instructions by specifying the six-digit numerical code.

1.9. Type label



1.9.1. Position of the type label on the container



2. Safety

2. Safety

2.1. Intended use

The FENECON Industrial XL is an industrial energy storage system consisting of various components. These include, in particular, efficient inverters, the FENECON Energy Management System (FEMS) and battery packs (including BMS) as well as a liquid cooling system and room air conditioning. The FENECON Industrial XL large-scale system is offered with an inverter output of 1500 kW and a capacity of 4072 kWh. The energy storage system is used to store and supply electrical energy and is intended for connection to the 400 V/50 Hz low-voltage grid. Any use beyond this purpose is considered improper use.

The electrical energy storage must only be used if no safety-relevant functions are linked to its function.

Use in safety-critical applications, such as for supplying power to medical devices, is not permitted.

2.2. Field of application

The product is intended exclusively for use in the following areas of application:

- Industrial sector

Any other use is not in accordance with the intended use.



Designed for use within Europe. For use outside Europe, please contact the FENECON Service.

2.3. Qualification of staff

To ensure that the system is used, installed and maintained as intended, only qualified personnel must be deployed. The area of responsibility, competence and supervision of the personnel must be precisely regulated by the operator.

The applicable regulations and rules of the German Social Accident Insurance (DGUV) must be observed during all activities on the electrical energy storage system, in particular during installation, operation, maintenance and servicing.

In particular, this includes the provisions of DGUV Regulation 3 (Electrical systems and equipment) and other relevant DGUV regulations and information. The operator is responsible for ensuring that only appropriately instructed and qualified persons carry out work on the system and that the general occupational health and safety guidelines are observed.

Compliance with the DGUV regulations is the responsibility of the operator and is a prerequisite for safe and legally compliant operation of the system.

2.3.1. Trained electricians

Trained electricians include persons who:

- are able to carry out work on electrical systems due to their technical training, experience and knowledge of the relevant standards and regulations.
- have been commissioned and trained by the operator to carry out work on electrical systems and equipment of the battery system.
- are familiar with how the battery system works.
- recognize hazards and prevent them by taking appropriate protective measures.
- Have access to all maintenance information.

2.3.2. Service personnel

Work that goes beyond connecting the system must only be carried out by the manufacturer's specialist personnel. Other personnel are not authorized to carry out this work.

Service personnel includes: Manufacturer's personnel or specialist personnel instructed and authorized by FENECON GmbH who must be requested by the operator to work on the electrical energy storage system (e. g. assembly, repair, maintenance, work on the batteries, etc.).

2.4. Safety and protective devices

The safety devices must not be bypassed or switched off. Operating the electrical energy storage system without or with defective protective devices is prohibited. The safety devices must always be kept within easy reach and checked regularly.

The safety devices are permanently integrated into the electrical energy storage system, so that no additional precautions are required during storage.

Maintenance of the safety devices is illustrated as part of the annual maintenance concept and must only be carried out by service personnel or authorized specialists.

All accesses to the electrical energy storage are locked with container doors. Access is only possible with a 4-digit numerical code. Only authorized specialist personnel must open the container.

2.4.1. Earthing connections/potential equalization

The electrical energy storage system has three earthing connections on the container and one earthing connection per inverter rack. The system also has two earth circuit connectors on the

2.4. Safety and protective devices

inverter racks.

The customer's PE connection in the control cabinet is made via the -X1 supply terminal and can be connected with a maximum cross-section of 50 mm².

All three PE connections on the customer side (1 x control cabinet, 2 x equipotential bonding rail— inverter rack) must be connected to the same equipotential bonding.

2.4.2. Lightning protection

If necessary, the operator is obliged to create a lightning protection concept for the electrical energy storage system and to integrate it into the lightning protection concept. The optional FENECON accessory package for lightning protection can be used for this purpose. If you are interested in option packages, please contact FENECON project at projekt@fenecon.de.

2.4.3. Fire alarm system

The FENECON Industrial XL is equipped with a fire alarm system. This is described in detail in the [Fire alarm system](#) section.

In the event of an alarm:

1. Pre-alarm: First point smoke detector has tripped.

Contactors of the batteries open.

Section switches in the inverters open.

Signal to customer interface relay:

for electrical energy storage systems with serial number 000001 to 000020: Alarm.

for electrical energy storage systems from serial number 000021: Pre-alarm.

Warning light: Only a visual signaling device on the container triggers (warning light).

2. Main alarm: Second point type smoke detector has tripped.

Signal to customer interface relay:

for electrical energy storage systems from serial number 000021: Main alarm.

Warning light: Only acoustic signal transmitter on the container triggers (siren).

2.4.4. Connection to fire alarm control panel (FACP)

The fire detection system can be connected to an external fire alarm control panel. The connection allows alarm and fault signals to be transmitted to an operator FACP.

Potential-free contacts are available for connection to an external alarm panel:

- 1 x fire alarm system pre-alarm (NO)
- 1 x main alarm (NO)
- 1 x malfunction of the fire alarm system (NC)
- 1 x fire extinguishing system tripped (NC) - optional
- 1 x fire extinguishing system blocked (NC) - optional

Max. voltage: 30 V DC

Max. switching/continuous current: 3 A

These are located in the control cabinet on the bottom row of the DIN rails of the Industrial XL:




Image 4. Connection to FACP

List item	=CONT+CC-X2
1	Terminal 5 Relay for fire alarm system (pre-alarm)
2	Terminal 6 Relay for fire alarm system (pre-alarm)
List item	=CONT+CC-X2
1	Terminal 7 Relay for fire alarm system (main alarm)
2	Terminal 8 Relay for fire alarm system (main alarm)
List item	=CONT+CC-X2
1	Terminal 9 Relay for fire alarm system (fault)
2	Terminal 10 Relay for fire alarm system (fault)

2.4. Safety and protective devices

List item	=CONT+CC-X2	
1	Terminal 11	Relay for fire extinguishing system (tripped)
2	Terminal 12	Relay for fire extinguishing system (tripped)
List item	=CONT+CC-X2	
1	Terminal 13	Relay for fire extinguishing system (blocked)
2	Terminal 14	Relay for fire extinguishing system (blocked)

Table 6. Connection to FACP—Terminal assignment

Connection cross-section (finely stranded, solid), min. 0.25 mm² (AWG 22), max. 4 mm² (AWG 12).

2.4.5. Faults in the fire detection system

- In the event of faults in the fire detection system, the manufacturer's installation and service instructions must be observed.

2.4.6. Maintenance of the fire detection system

- Maintenance work on the fire alarm system must only be carried out by a VdS-approved specialist company or by qualified specialists for fire alarm systems (qualified specialist for fire alarm systems in accordance with DIN 14675).

2.5. Residual risks

2.5. Residual risks



The product is manufactured in accordance with the current state of the art and recognized safety principles, taking into account the relevant statutory regulations.

Nevertheless, handling the product may pose a risk to people and/or the environment.

No access for unauthorized persons!

There is a risk of death or serious injury from unexpected incidents in the entire danger zone.



- Do not enter the danger zone.
- Before entering hazardous areas, switch off the electrical energy storage system and secure it against being switched on again.
- Only authorized personnel are permitted to enter hazardous areas.

Safety: Ensure that no unauthorized persons are present in the areas.

Danger of electric shock

Contact with live components can lead to death or serious injury.



- Do not touch any exposed live parts.
- Insulated components must not be opened or manipulated.
- Avoid contact with live parts.

Work on live components of the electrical energy storage system must only be carried out by authorized service personnel.

Danger of burning



There is a risk of burns on hot cables and housing surfaces in the event of direct contact with uninsulated surfaces and hot media. The hazard points are marked with corresponding pictograms.

- Do not touch the hazard point.



Note This signal word indicates actions to prevent damage to property. Observing these instructions prevents damage to or destruction of the system.

2.6. Safety instructions

2.6.1. General information on the electrical energy storage system

- Select the installation site of the system so that a minimum clearances of 5 m from buildings or comparable structures is maintained.
- Roofing of the electricity storage system and its components by the customer is not permitted.
- The system's protection specification against water is IP54. It is protected against splashing water on all sides, but not against water jets, temporary submersion or flooding (high water). Installation in areas at risk of flooding is technically possible, but is at the sole responsibility and risk of the operator.
Any warranty and liability claims for damage caused by water ingress as a result of flooding, high water, water jets or standing water are excluded.
- The electrical energy storage system must be installed on a level and load-bearing surface. The [Industrial XL installation concept](#) must be observed.
- The operator must meet the requirements for the floor conditions, which can be found in the [Industrial XL installation concept](#).
- Read the instructions for installation and operation to avoid damage due to incorrect installation/operation.
- Only operate the system under the specified environmental conditions.
- The electrical energy storage system must only be used under the specified charging/discharging conditions (see [Technical data](#)).
- Only authorized persons must operate and maintain the electrical energy storage system. Access is prohibited for children and unauthorized persons. Keep animals away from the electrical energy storage system as they can damage cables or other components and thus cause hazards.
- The battery packs may have insufficient cell voltage after a long storage period. For more information, see section [Storage](#).
- The operator is prohibited from charging the battery packs with an external charger.
- Do not expose the battery packs to high voltage.
- Do not short-circuit/bridge the batteries.
- Do not touch the battery plugs (+) and (-) directly with a wire or metal object (e. g. metal chain, hairpin). Excessive current can be generated in the event of a short circuit, which can lead to overheating, explosion or fire of the battery packs.
- The battery packs must only be removed or replaced by service personnel.
- Only transport the battery packs as hazardous goods.
- Observe the applicable laws, regulations and standards when transporting the battery packs.

2.6. Safety instructions

- Before transport, ensure that the battery packs fulfill the indicated transport requirements (e.g. defined state of charge, secured connections, protective covers). This is the only way to ensure safe and compliant transportation.
- Only use the battery packs as intended. Improper use can lead to overheating, explosion or fire of the battery packs.
- Do not dismantle or modify the battery packs. The battery packs integrate a safety mechanism and a protective device, damage to which can lead to overheating, explosion and/or fire of the battery packs.
- Protect the area of the electrical equipment and batteries from moisture and water.
- Prevent water ingress when working on the electrical energy storage system.
- Do not apply any mechanical force to the battery packs. The battery packs can be damaged and short circuits can occur, which can lead to overheating, explosion or fire of the battery packs. If damage to the battery packs is detected, contact FENECON Service immediately.
- Do not crush, throw, drop or attempt to open the battery packs. Do not use the dropped battery pack and contact FENECON Service immediately.
- Do not place any objects on the battery packs.
- Do not step on the battery packs.
- Do not use the battery packs if, during assembly, charging, normal operation and/or storage, changes in color, mechanical damage, leakage of liquids or deformation are detected or if evaporating gases can be smelled. If one of the cases mentioned here occurs, contact FENECON Service immediately.
- If a battery exhibits unusual odours, excessive heating, a change in color or shape, leaking electrolyte solution or other abnormalities, it must be reported to authorized service personnel immediately. Otherwise there is a risk of overheating, explosion or fire. Only authorized service personnel must remove the battery from the battery tower.
- Eye and skin contact with leaked electrolyte solution must be avoided. After contact with eyes or skin, rinse/clean immediately with water and seek medical attention. Delayed treatment can cause serious damage to health.
- No work such as soldering, welding, drilling, grinding or other mechanical or thermal processing must be carried out on the battery packs or in their immediate vicinity. Work of this kind entails the risk of flying sparks, the formation of chips or the effects of heat. This can damage the insulator and the safety ventilation mechanism and lead to overheating, explosion or fire of the battery packs

2.6.2. Installation, operation and maintenance

Always observe the following safety instructions when installing, operating or maintaining the battery packs:

- Installation work on the electrical energy storage system and making the cable connections must only be carried out by authorized and trained electricians.
- Commissioning and maintenance work on the battery packs or the electrical energy storage system must only be carried out by authorized service personnel.
- During assembly and maintenance work on the battery tower, stand on dry insulating objects and do not wear any metal objects (e. g. watches, rings and necklaces) during maintenance work/operation.
- Use insulated tools and wear personal protective equipment.
- The battery packs can cause electric shock and burns due to short-circuit currents.
- Do not touch two charged contacts with a potential difference.
- Check that there is no voltage present on the battery pack using a two-pole voltage tester in accordance with DIN VDE 0682-401.
- If an anomaly is detected, actuate the maintenance switch (if directly accessible).
- Do not continue the maintenance work until the cause of the fault has been rectified.

2.6.3. Fire protection

- Do not heat the battery packs. Excessive overheating can cause insulation materials to melt. This can cause the battery packs to explode or catch fire.
- Do not expose the battery packs to open fire or dispose of them in a fire.
- Do not set up or use any open sources of fire, heating or high temperatures in the vicinity of the electrical energy storage unit.
- Keep the battery packs away from sources of heat and fire, flammable, explosive and chemical materials.
- Avoid contact between the battery packs and conductive objects (e. g. wires).
- Use the operating fluids and coolants specified by the manufacturer.
- Maintain the prescribed clearances around the electrical energy storage system in accordance with the [installation concept](#).
- Fire, open light and smoking in the installation area of the electrical energy storage system is prohibited.
- The fire alarm system must only be serviced by service personnel.

2.7. Behavior in emergency situations

In an emergency (e. g. smoke, fire, unusual noises or odors), proceed as follows:

1. Disconnect the electrical energy storage system from the grid as far as safely possible.

2.7. Behavior in emergency situations

2. Leave the danger zone immediately.
3. Cordon off the danger zone and prevent access.
4. Alert the relevant emergency services.
5. Warn neighbors and other persons at risk immediately.
6. Do not attempt to extinguish the fire yourself. Extinguishing must only be carried out by the emergency services using suitable means (see fire protection in [Applicable documents](#)).

2.8. Reasonably foreseeable misuse

All applications that do not fall within the scope of the intended use are considered misuse.

Work on live parts is generally not permitted. Electrical work must only be carried out by qualified electricians.

The following safety rules must be observed for all work on electrical components:

1. Disconnect.
2. Secure against restarting.
3. Check that there is no voltage.
4. Earth and short-circuit.
5. Cover or shield neighboring and live parts.

Non-compliance with the safety rules is considered a reasonably foreseeable misuse.

Other misuses include in particular:

- improper transportation, installation, assembly, trial operation or operation that may damage the product,
- change in the specified technical characteristics, including the individual components,
- change or deviation of the connected load,
- functional or structural changes,
- Operating the product in a faulty or defective condition,
- improper repairs,
- use by untrained persons (instruction in accordance with the installation and service instructions is provided by the operator),
- operation without safety devices or with defective safety devices,
- Disregarding the information in the original operating instructions,
- unauthorized access via the control unit or the network,
- Fire, open light and smoking in the vicinity of the storage system,
- insufficient ventilation,
- Unauthorized changes and actions to the storage system,
- Private use,
- Use as mobile energy storage,
- Direct use in a PV system (only one AC-side grid feed-in possible).

2.9. Pictograms

2.9. Pictograms

Pictograms on the system indicate dangers, prohibitions and instructions. Replace illegible or missing pictograms with new ones.


Pictogram	Meaning	Position
	Warning of dangerous electrical voltage	Pictogram on the enclosure, and marking of components which do not clearly indicate that they contain electrical equipment which may be the cause of a risk of electric shock.
	Warning against corrosive substances	On the battery packs.
	Ground before use	In the area of the earthing connections (e. g. on the container)
	Separate collection of electrical and electronic equipment	On the battery packs.
	Warning against hand injuries	
	Warning of hot surface	
	General warning sign	
	Warning of danger from charging batteries	On the battery packs.

Table 7. Pictograms — Warning signs

Pictogram	Meaning	Position
	General prohibition sign	
	No open flames; fire, open sources of ignition and smoking prohibited	
	No access for persons with pacemakers or implanted defibrillators	
	No access for unauthorized persons	
	Follow instructions	
	Use protective headgear	
	Use protective footwear	
	Use protective gloves	

Table 8. Pictograms — Prohibition signs and mandatory signs

2.10. Operating materials/equipment

2.10.1. Electrolyte solution of the battery packs

- Electrolyte solution is used in the battery packs (NMC).
- The electrolyte solution in the battery packs is a clear liquid and has a characteristic odor of organic solvents.
- The electrolyte solution may crystallize after discharge.
- The electrolyte solution in the battery packs is flammable and corrosive.
- Contact with electrolyte solution can cause severe burns to the skin and damage to the eyes.
- Do not inhale the vapors.
- Leave the contaminated area immediately after inhaling vapors.

2.10. Operating materials/equipment

- If the electrolyte solution is swallowed, induce vomiting.
- After contact with skin, wash thoroughly with soap and water.
- After contact with eyes, rinse as soon as possible with running water for 15 minutes. Consult a doctor immediately.



Further information on the electrolyte solution can be found in the safety data sheet for the batteries.

2.10.2. Agent of the cooling system



The coolant used in the cooling system is R513a.

- Contains pressurized gas. The container may explode if heated.
- Rapid evaporation or contact with the liquid can cause frostbite.
- The vapors are heavier than air and can accumulate in deep areas, reducing the oxygen concentration.
- If concentrations are too high, anesthetic effects may occur.
- Misuse or intentional inhalation can be fatal without alarming symptoms due to effects on the heart.
- Inhalation of the coolant can cause cardiac arrhythmia.
- Thermal decomposition can produce toxic and corrosive compounds.

2.10.3. Electrical equipment

- Work on electrical equipment must only be carried out by trained electricians.
- Maintenance work must only be carried out by trained specialist personnel (service personnel).
- Before starting work on the electrical energy storage system, visually check for insulation and housing damage.
- Regularly carry out checks for insulation and container/housing damage.
- The system must never be operated with faulty or non-operational electrical connections.
- Only insulated tools must be used for maintenance on uninsulated conductors and terminals.
- Control cabinets (e. g. inverter housing) must always be kept locked. Only authorized personnel with appropriate training and safety instructions (e. g. service personnel) should be allowed access.
- The inspection and maintenance intervals for the electrical components specified by the manufacturer must be observed. Details can be found in the maintenance instructions.

- To avoid damage, lay supply lines without crushing and shearing points.
- If the main switch is disconnected, specially marked external circuits may still be live!
- Dangerous residual voltages may still be present on some equipment (e. g. inverters) with an electrical intermediate circuit for a certain period of time after disconnection. Check that there is no voltage on these systems before starting work.

2.11. Notes on occupational health and safety

The obligations arising from occupational health and safety must be implemented by the operator of the low-voltage equipment.

Operator obligations in relation to the use of the product:

- Making these installation and service instructions or extracts thereof available to persons who perform tasks with or in connection with the product.
- Provide the [Applicable documents](#) to these persons.
- Instruction of persons with regard to the intended use as well as the prohibited use.
- Instruction of persons with regard to safety devices and supplementary protective devices.
- Instruction of persons with regard to all residual risks.

2.12. Personal protective equipment

2.12. Personal protective equipment

Depending on the work carried out on the system, wear PPE (personal protective equipment):

- Protective footwear.
- Protective gloves, cut-resistant if necessary.
- Protective eyewear.
- Protective headgear.
- Safety vest.
- Fall protection.
- First aid kit.

2.13. Spare and wear parts

The use of spare and wear parts from third-party manufacturers can lead to risks. Only original parts or spare and wear parts approved by the manufacturer must be used. The instructions for spare parts must be observed.



Further information must be requested from the manufacturer.

2.14. IT security

FENECON energy storage systems and their applications communicate and operate without internet connection. The individual system components (inverters, batteries, etc.) are not directly connected to the internet or accessible from the internet. Sensitive communications via the internet are processed exclusively via certificate-based TLS encryption.



- Access to the programming levels is not barrier-free and is accessible at different levels depending on the qualifications of the operating personnel. Safety-relevant program changes require additional verification.
- FENECON processes energy data of European customers exclusively on servers in Germany and these are subject to the data protection regulations applicable in this country.
- The software used is checked using automated tools and processes established during development in order to keep it up to date and to rectify security-relevant vulnerabilities at short notice. Updates for FEMS are provided free of charge for life.

3. Technical data

3.1. General




Image 5. Electrical energy storage system — Overview

3.2. System overview

3.2. System overview

3.2.1. Physical overview




Image 6. Physical overview — front




Image 7. Physical overview — rear

1	Battery container	3	Inverter rack next to cooling system
2	Inverter rack front	4	HYDAC liquid cooling system

Table 9. Physical overview

3.2.2. Block diagram

Complete block diagram as download (PDF)

See [Applicable documents](#) for URL.

3.2. System overview

3.2.3. Network plan

Complete network diagram as download (PDF)

See [Applicable documents](#) for URL.

3.3. Battery container




Image 8. Battery container (open)




Image 9. View — Control cabinet (open)

3.3. Battery container

1	Battery rack 1	8	Cable bushing — Inverter
2	Battery rack 2	9	F2B box
3	Battery rack 3	10	Explosion vent panels
4	Control cabinet	11	Room air conditioning system
5	Manual activation switch	12	Cable bushings — Inverter
6	Visual and acoustic signaling device	13	Overvoltage protection — Inverter communication
7	Cable bushings — Control cabinet		

Table 10. Battery container (open)

3.3.1. Steel construction — Battery containers




Image 10. Steel construction — Battery containers

The underlying steel construction of the FENECON Industrial XL has been statically tested and meets all requirements.

The surface coating is RAL9010 pure white in accordance with C4H.

The weight of the steel structure is **6,340 kg**. It is manufactured in Germany.

3.3.2. Control cabinet




Image 11. Control cabinet components (external)

1	Service socket	5	Container lighting OFF/ON
2	Service network interface	6	Maintenance switch
3	CAN bus interface Rack 1-3	7	Buffering 24 V Rack 1-3 OFF/ON
4	Main switch	8	Indicator lights: green (operation), yellow (warning), red (fault)

Table 11. Control cabinet components (external)

3.3. Battery container




Image 12. Control cabinet components (internal)

1	AC feed-in/interface — Customer	6	Network
2	Interface — Container/air conditioning	7	24 V distribution — F2B
3	AC supply	8	Control cabinet thermostat
4	Interface — Control cabinet door	9	24 V supply — F2B
5	24 V distribution (internal)	10	FEMS/IO system

Table 12. Control cabinet components (internal)

3.3.3. AC connection area




Image 13. AC connection area

- AC connection (customer-side)
- Max. connection cross-section: 50 mm²
- Pre-fuse: 80 A, operating class: gG

For a TN-C grid, use the optionally supplied jumper between -X1.9 and -X1.10.

If a PEN conductor is used, an N conductor must not be connected.

3.3.4. DC connection area




Image 14. DC connection area

1	DC connection plate for battery tower 1	3	DC connection plate for battery tower 3
2	DC connection plate for battery tower 2		

3.3. Battery container

Table 13. DC connection area

3.3.5. Feedthroughs




Image 15. Feedthroughs

1	Feedthroughs — Control cabinet	3	Feedthroughs — Cooling system
2	Feedthroughs — Inverter		

Table 14. Feedthroughs

3.3. Battery container




Image 16. Feedthroughs—Control cabinet

1	AC supply—Customer, max. 50 ² (cable diameter 34-48 mm)	3	Internet—Customer (2 x cable diameter 13-21 mm)
2	Communication connection—Customer . Inverter release . RS485 bus interface . Fire alarm/extinguishing system (7 x cable diameter 9-17 mm)		

Table 15. Feedthroughs—Control cabinet




Image 17. Cable glands — Inverters

1	DC inverter rack 1/front	3	DC inverter rack 2/cooling
2	Communication — Inverter rack 1/front	4	Communication — Inverter rack 2/cooling

Table 16. Cable glands — Inverters

3.3. Battery container




Image 18. Feedthroughs—Cooling system

1	Cooling system supply and return lines	3	Communication—Cooling system
2	AC supply—Cooling system	4	Maintenance access—Connection area

Table 17. Feedthroughs—Cooling system


3.3.6. Battery tower


Image 19. Battery tower

1	Steel frame	6	Grounding cable — Battery
2	Battery pack	7	Serial air conditioning connection in a battery ring
3	HV800 box (high-voltage 800 V box) on carrier plate	8	Communication connection battery to F2B
4	Amphenol DC connector on batteries	9	F2B-to-HV800 communication connection
5	F2B box (FEMS-2-Battery box) on carrier plate	10	Rollers of the battery tower

3.3. Battery container

Table 18. Battery tower

3.3.7. Battery




Image 20. Battery—front view




Image 21. Battery—rear view

1	Cooling water connection supply and return	3	Front HV connections
2	Additional HV connection	4	Additional HV connection (rear)

Table 19. Battery


3.3.8. Cooling system distribution


Image 22. Cooling system distribution

1	Cooling system supply and return lines for battery towers 1 and 2	3	Junction box of the cooling system distribution at the container for supply and return
2	Cooling system supply and return lines for battery tower 3		

Table 20. Cooling system distribution

3.3. Battery container

3.3.9. Fire alarm system (FAS)

The fire alarm system is installed and checked at the factory. Maintenance and service work on the fire alarm system must only be carried out by authorized specialist personnel. Safety-relevant information can be found in the [Safety](#) section.

In the event of an alarm or malfunction, contact the FENECON service personnel.



To restart the system after a false alarm/fault, acknowledge the fire detection system alarm on site.



Test the fire alarm system with test gas. Use test gas [ALL081] *Test gas test aerosol 918-5 250 ml* for this purpose.




Image 23. Fire alarm system — Fire alarm control panel




Image 24. Fire alarm system — Multi-detector sensor

3.3. Battery container




Image 25. Fire alarm system - switches and signaling devices

1	Fire alarm control unit	4	Manual activation switch
2	Multi-detector sensor	5	Audible and visual signaling device
3	Multi-detector sensor		

Table 21. Fire alarm system

3.3.10. Lightning protection system




Image 26. Lightning protection system

1	Lightning rods	3	Wall mountings
2	Support tubes	4	Insulated cables

Table 22. Lightning protection system

3.4. Inverter rack

3.4. Inverter rack




Image 27. Inverter rack

1	Steel frame	5	Roof
2	Vibration damper	6	Lifting eyebolts (4 x per inverter rack)
3	Inverter (9 per inverter rack)	7	Cable ladders
4	Lifting points for transportation (4 x per inverter rack)		

Table 23. Inverter rack

3.4.1. Steel construction — Inverter rack




Image 28. Steel construction — Inverter rack

The steel construction of the FENECON Industrial XL has been statically tested and meets all requirements.

The surface coating corresponds to corrosion protection class C4H and is finished in RAL 9010 pure white.

The weight of the steel structure is 640 kg. It is manufactured in Germany.

3.4. Inverter rack

3.4.2. Inverter



Image 29. Inverter




Image 30. Inverter—Junction box

3.4.3. Cable ladder




Image 31. Cable ladder

The color coding of the cables in the picture above is as follows:

- Orange = AC cable of the customer
- Black = DC and communication cable
- Green/yellow = grounding cable

The DC cables are laid in the lower area of the cable ladders.

The customer's AC cables are laid in the upper area.

- Single wires with a maximum cross-section of 150 mm² are permitted.
- The cable ladder is not designed for AC feed lines in multiple cable bundles.

3.4. Inverter rack

The side channels are intended for the customer feed of the AC cables. The middle channel is intended for the DC and communication connections to the battery container.




Image 32. Equipotential bonding bar

The customer can connect up to two protective conductors of the AC supply to the equipotential bonding rail of the inverter rack (see image). By using two protective conductor cables, the required cross-section can be divided accordingly. The duplicate design of the protective conductor

connections ensures redundancy and thus additional safety.

3.5. Cooling system

3.5. Cooling system




Image 33. Cooling system

1	Drip tray	6	Electrical interface — Power supply
2	Roof	7	Temperature controller
3	Connection/Flow	8	Main switch
4	Connection/Return	9	Cover plate — Maintenance access
5	Electrical interface — Signal		

Table 24. Cooling system

3.6. Cable bridges

3.6. Cable bridges




Image 34. Cable bridges

The cable bridges between the inverter racks and the container are installed by the service personnel during commissioning. The DC and communication cables of the inverter racks are routed to the inverter connection of the container via these cable bridges.



When laying cables, ensure that the cables are only laid next to each other. Overlapping of cables is not permitted.

4. Installation preparation

4.1. General description




Image 35. Standardized system configuration

Standardized system configuration, generally valid for all FENECON industrial storage systems. Details vary depending on the electrical energy storage system. This system configuration can be an example for the application of self-consumption optimization.

Residual risks:



Misoperation

Incorrect operation can lead to serious injury or death.

- Before switching on the individual components, observe the specifications and instructions in the respective manufacturer's documentation.

4.2. Scope of delivery



Misoperation can lead to material damage.
Before switching on the system, make sure that

- all safety devices are fitted,
- there are no persons in the danger zone.

4.2. Scope of delivery

List item	Component	Amount	Item no.	Comment
1	Container incl. 36 batteries, room air conditioner and cabling	1	BGI0764 (pre-series)	Transport reinforcement of the container back to FENECON
2	Inverter rack front with 9 inverters each (KACO bp 92.0 TL3-S)	1	BGI0387	
3	Inverter rack climate with 9 inverters each (KACO bp 92.0 TL3-S)	1	BGI0388	
4	HYDAC cooling system	1	ZUI2191	
5	Drip tray and roof for the climate control unit	1	ZUI2192	
6	Cable jumper set inverter rack to container	1	BGI0782	
7	Cooling cable jumper set	1	BGI0788	
8	Drums with coolant (water/glycol) 220 liters each	2	ZUI2841	Return to FENECON
9	Canisters with coolant (water/glycol) 30 liters each	1	ZUS830	Return to FENECON
10	Grid box with cable bridges and hose set	1	BGI0786 (pre-series)	Return to FENECON

Table 25. Scope of delivery

Software licenses for operating the system are not included in the standard scope of delivery. The applications *Read and Write Access (REST/JSON and Modbus/TCP, Self-Consumption Optimization, Peak Shaving (phase-accurate) and Time Slot Peak Shaving* can be purchased optionally. These can be installed both retrospectively and directly during commissioning. The instructions for FEMS applications for the electrical energy storage system can be found at docs.fenecon.de.

4.3. Tools/machines required

The following tools are required for assembling of the system components:

Description	Comment
Crane	Crane with chain sling (minimum length of chain sling 6.5 m) (container weight 32 t fully loaded) Observe lifting instructions.
Multimeter	
Socket wrench set/ratchet box	
Hexagon socket wrench set	
Measuring tape/measuring device for setting up the components	
Qualified electrician's toolbox	

Table 26. Tools required

5. Assembly—General

5. Assembly—General

The AC connections and inverters are assembled and installed by the operator. Please make an appointment in advance with your contact person at FENECON for the subsequent commissioning.

FENECON GmbH
Gewerbepark 6
94547 Iggensbach
Germany
+49 (0) 9903 6280 0
aftersales.industrial@fenecon.de

Residual risks:

	Misoperation Incorrect operation can lead to serious injury or death. Before switching on the individual components, observe the specifications and instructions in the operating/assembly instructions of the respective manufacturer.
	Incorrect operation can lead to material damage. Before switching on the system, make sure that <ul style="list-style-type: none">• all safety devices are installed and active,• there are no persons in the danger zone.

The following components must be installed or connected by the operator:

- Container
- 2 inverter racks with 9 inverters each
- Cooling system

Before installation, carefully check whether the products are damaged and whether all accessories listed in the scope of delivery are included. If a part is missing or damaged, contact the manufacturer/dealer.

5.1. Select installation site



Installation site

- Only install the system outdoors.
- Avoid dirt and dust during assembly and installation.
- Do not install the electrical energy storage system in an area that is at risk of flooding.
- Do not install the electrical energy storage system where the ambient conditions are outside the operating requirements.
(Max. 2000 m above sea level — For more information see: Section: [Technical data](#)).
- Keep the slide-in battery modules away from heat sources and fire.
- The electrical energy storage system must be set up in such a way that only authorized personnel have access to it.

The operator of the system is responsible for selecting and preparing a suitable installation site for the energy storage system. It must be ensured that the ground is suitable for the use of a crane. The [lifting instructions](#) must be observed for the design of the crane and the lifting beam. Sufficient clearance must also be ensured in front of the container. The requirements for the installation site from the FENECON installation concept must be met.

The BESS FENECON Industrial XL must be installed and operated outdoors.

5.2. Assembly steps

5.2. Assembly steps




Image 36. Electrical energy storage system — rear view

5.2.1. Unloading the container

Use a crane for lifting the container. Strictly adhere to the lifting instructions! When setting down the container, please observe the foundation and load transfer recommendations.

5.2.2. Unloading the inverter racks

Use a crane to unload the inverter racks. Strictly adhere to the lifting instructions! Please observe the foundation and load transfer recommendations when setting down the inverter racks.

5.2.3. Unloading the liquid cooling system

Use a crane to unload the HYDAC liquid cooling system. Follow the manufacturer's lifting instructions! See [Applicable documents](#). Please observe the foundation and load transfer recommendations when setting down the inverter racks. Installation sequence:

1. Set up and align the drip tray.
2. Place the HYDAC liquid cooling system on the drip tray.

3. Install the roof on the liquid cooling system.

5.2.4. Install equipotential bonding/earthing

An earthing connection can be made to the container and the inverter racks. The electrical energy storage system must be integrated into the on-site lightning protection concept and the corresponding earthing and equipotential bonding cables must be connected to the marked points. The instructions in the installation concept must be observed.

5.2.5. Wiring the AC/DC connections



The AC supply for the container must be designed by the customer and is therefore not included in the scope of delivery.



Attention: Lay individual wires!

6. Network connection

The network connection and communication to FENECON Industrial XL is implemented as follows by default:

6.1. Standard setup — Internet via fiber optics




Image 37. Internet via fiber optics

Internet — Standard via SFP: Only one connection via optical fiber is required. The internet connection must be established in accordance with the information in the section [Technical documentation FEMS](#). Communication with the power plant controller and controller of the energy storage system is also implemented via this interface as standard.

6.2. Internet via ETH



The SFP+ module for the fiber optic connection must be provided by the customer. For technical queries or further coordination, please contact FENECON project management.

Superordinate EMS (MB TCP): If the internet connection is to be separated from the rest of the network, establish a physical separation via a second Ethernet connection. This allows the energy storage system to be integrated into a local network without having to establish an internet connection.



The separate internet connection is still necessary!

6.2. Internet via ETH

If the internet connection is not to be established via fiber optic, but via Ethernet, it is necessary to purchase the additional package "Internet via ETH". This consists of an additional overvoltage protection, an ETH/SFP module and an additional connection cable. These components must be installed according to the Industrial XL instructions. Please note the maximum cable length of the option.




Image 38. Internet via ETH

The option **Superordinate EMS (MB TCP)** remains unaffected by this and can be set up in the same way as in the previous section.

6.3. General information

- There is no option to provide the internet via a SIM card to be integrated.
- An unrestricted internet connection is required to ensure optimal operation.
- The maximum cable lengths of the supply lines used must always be observed.

- The Ethernet cable must NOT be connected directly to the system router, only SFP!
- The system is operated with the [FEMS App Modbus/TCP write access](#) by default.

7. Initial commissioning

7. Initial commissioning

The initial commissioning is carried out by FENECON GmbH. Please arrange an appointment for commissioning in advance with your contact person at FENECON GmbH.

FENECON GmbH
Gewerbepark 6
94547 Iggenbach
Germany
+49 (0) 9903 6280 0
aftersales.industrial@fenecon.de

Residual risks:

	Misoperation Incorrect operation can lead to serious injury or death. Before switching on the individual components, observe the specifications and instructions in the operating/assembly instructions of the respective manufacturer.
	Incorrect operation can lead to material damage. Before switching on the system, make sure that <ul style="list-style-type: none">• all safety devices are fitted,• there are no persons in the danger zone.

8. FEMS — FENECON Energy Management System

8.1. Technical documentation — FEMS

The technical documentation of FEMS must be observed; this can also be found on the FENECON website at: www.docs.fenecon.de.

1. Internet connection

A permanent internet connection for the FEMS is recommended and is necessary for commissioning. In principle, offline operation is also possible. In this case, however, the following functions cannot be used:

Remote commissioning, system updates, installation of new FEMS Apps, transfer of measurement data to FENECON servers for remote access, use of Online Monitoring via the FENECON portal access (e. g. for on the go via smartphone), maintenance access for FENECON Service employees, use of FEMS Apps with third-party services via the internet (e. g. Time-of-use tariffs).

2. Network configuration

In the standard configuration, FEMS obtains the IP address via a DHCP server (e. g. FritzBox). The network configuration can also be adjusted in Online Monitoring under Settings & Network configuration. More information can be found [here](#).

3. System update

The system is regularly updated as part of software updates. These updates can be installed via the Settings & FEMS system update tab.

8.2. Online Monitoring

8.2. Online Monitoring

The FEMS Online Monitoring is used to visualize all energy flows in the system. The energy monitor shows live data on grid withdrawal or grid feed-in, PV production, charging/discharging of the battery storage system and electricity consumption. Other widgets show the percentage of self-sufficiency and Self-consumption. In addition, the individual widgets offer a detailed view, which can also be used to view the performance values with phase accuracy.

In addition to the pure information display, Online Monitoring also lists all additionally purchased FEMS extensions, such as phase-accurate Peak Shaving, self-consumption optimization, Time Slot Peak Shaving. Their functionality can be controlled via the corresponding widget. The integration of a PV system or other generators is also possible with the FEM112 package.

In addition to the live view, the history offers the option of selecting self-selected time periods for Online Monitoring.

The status of both the overall system and the individual components can be monitored at any time using the info icon.

The technical documentation of FEMS must be observed; this is also available on the FENECON website at: www.docs.fenecon.de/.

8.3. Access data

Access to FEMS Online Monitoring is separated according to end customer and installer.

8.4. Overview




Image 39. FEMS Online Monitoring

9. Troubleshooting

Residual risks:



If a fault is present and is not displayed in the fault message list, inform customer service.



Unknown fault messages

Unknown faults and attempts to rectify them can damage the product.

- If a fault is present and is not displayed in the fault message list, inform customer service.

9.1. FEMS Online Monitoring

The system status can be checked after logging in at the top right using the color of the icon.

9.1.1. Fault display

	System status: Everything is OK
	System status: Warning
	System status: Error (Fault)

Table 27. Fault display

9.1. FEMS Online Monitoring

9.1.2. Troubleshooting



	<p>For a detailed overview of an existing warning or error, click on the exclamation mark in the top right-hand corner.</p>
	<p>You can use the scroll bar to examine the origin of the warning or error in more detail.</p> <p>In this example, the error lies with the controller used.</p>
	<p>Clicking on the icon (down arrow) displays a more detailed error description depending on the error.</p>

Table 28. Troubleshooting

In the example above, an incorrect reference for the grid meter was intentionally entered for test purposes, which is why the controller execution fails.

The FENECON Service must be contacted to rectify errors.

	<p>Under certain circumstances it can happen that the FEMS is not accessible and the adjacent error message appears.</p>
--	--

If the FEMS is offline, follow the steps displayed below the message.

9.2. FENECON Service



These installation and service instructions only contain work that can be carried out without specialist knowledge of the manufacturer.



Work that is not described must only be carried out by authorized service personnel. Contact customer service to change parameters and programs.

If the energy storage system malfunctions, contact the FENECON Service:

Phone: +49 (0) 9903 6280 0

E-mail: aftersales.industrial@fenecon.de

9.2.1. Details for the FENECON Service

The following information must be provided for the FENECON Service:

- Device type/configuration.
- FEMS number.
- Serial number.
- The currently installed software version.
- Ticket number from previous faults (if available).
- Inverter error code (if available).

The information can be found on the type label and in the system profile in Online Monitoring.

9.2.2. Service times

Monday to Thursday: 08:00 a.m. to 12:00 p.m. | 1:00 p.m. to 5:00 p.m.

Friday: 08:00 a.m. to 12:00 p.m. | 1:00 p.m. to 3:00 p.m.

10. Technical maintenance

10. Technical maintenance

10.1. Tests and inspections

Residual risks:



When carrying out inspection work, ensure that the product is in a safe condition. Improperly performed inspections can have serious consequences for people, the environment and the product itself.



Inspection work must only be carried out by trained and qualified specialists.



The maintenance instructions for all individual components must be observed by authorized qualified electricians.

Check the product and the cables regularly for visible external damage. If components are defective, contact the FENECON Service. Repairs must only be carried out by a qualified electrician.

10.2. Cleaning

Cleaning agents

The use of solvents, cleaning agents and high-pressure or steam jets can damage the electrical energy storage system and its parts.



- Only clean the electrical energy storage system with a damp cloth. Use clean water to moisten the cloth.
- Electrical components must never come into contact with water or cleaning agents.

10.3. Maintenance work

Residual risks:



During maintenance work, troubleshooting and assembly activities, ensure that the product is switched off in a safe manner and secured against being switched on again. Improperly performed maintenance and servicing activities can have serious consequences for people, the environment and the product itself.

Before carrying out maintenance work on systems which could be under pressure or in which very hot/hazardous substances could still be present:



1. Switch off the system.
2. Secure the system against being switched on again.
3. Wear personal protective equipment against scalding/burns.
4. Switch off/disconnect loads.
5. Allow the system to cool down.
6. Check whether hazardous substances are still in the system.



The product must only be serviced by persons who have received detailed instruction on the subject.



The frequency of use and environmental conditions can make it necessary to vary the intervals between the activities described below.

- Instruct the persons responsible for maintaining the product.
- After consulting the manufacturer, change the maintenance intervals in this documentation.



Maintenance work must only be carried out by trained and qualified specialists.

For maintenance of the inverters and the liquid cooling system, please refer to the documentation of the individual manufacturers and the FENECON maintenance instructions.

10.4. Repairs

Contact the FENECON Service the event of defective components.

11. Storage

11. Storage

Storage up to 3 months

Desiccant bags are used to prevent condensation forming in the container during storage.



There are six desiccant bags in the container on delivery. Remove them after commissioning. Replace the desiccant bags after a storage period of 3 months.

Storage longer than 6 months

Possible consequences: Deep discharge of the cells and defect of the battery modules.



- External charging of the battery modules to nominal voltage — forced charging must be carried out, which is controlled via the FEMS.

This must only be carried out by the manufacturer or by a company commissioned by the manufacturer.

- Do not store the energy storage system together with flammable or toxic objects.
- Store energy storage systems with safety defects separately from undamaged ones.
- The SoC of the individual batteries in the energy storage system is $\geq 25\%$ SoC on delivery.
- The SoC of the individual batteries should be within a range of 25 to 75 %. If this is not the case, charge or discharge the batteries accordingly.
- Recharging the slide-in battery modules is recommended from an SoC of $<25\%$.

Storage area: Fireproof indoors/outdoors with suitable weather protection

- Air temperature: $-20\text{ }^{\circ}\text{C}$ to $40\text{ }^{\circ}\text{C}$.
- Relative humidity: max. 50 % at $+40\text{ }^{\circ}\text{C}$.

11.1. Commissioning instructions — Room air conditioning

Rev. 01 — Status: October 2025

11.1.1. General



For each storage and interim storage of the electricity storage system Industrial XL, it must be ensured that the room air conditioning is connected and in operation. A separate, customer-side connection is required for this.

11.1.2. Installation site

Open the front of the container for installation. The air conditioning is located on the left-hand container wall.




Image 40. Position of the air conditioning in the container

11.1. Commissioning instructions — Room air conditioning

11.1.3. Electrical connection

A UV/weather-resistant cable with a cross-section of $5 \times 1.5 \text{ mm}^2$ or $5 \times 2.5 \text{ mm}^2$ can be used for the electrical connection.

Fuse protection is provided by a three-pole miniature circuit breaker with a B16 A characteristic provided by the customer.

The connection cable must be fed into the container underneath the air conditioner via a cable gland on the flange plate.




Image 41. Cable glands on flange plate

The room air conditioning is installed to the device at terminal X1.



Image 42. Connecting the room air conditioning

After the miniature circuit breaker has been racked in, the device automatically starts operation. Manual operation is *not* required.

12. Utilization load

12. Utilization load

The service life of the product depends on the service life and maintenance intervals carried out by specialist personnel. The service life is particularly influenced by preventive maintenance and servicing. Timely replacement of wearing parts and appropriate documentation of each activity is therefore crucial for the availability of the product.

All functional safety elements must be replaced in accordance with the number of operating cycles or operating time specified by the manufacturer before the calculated or specified service life is reached.

The manufacturer must be contacted after 20 years at the latest in order to determine the further procedure with regard to revision or replacement.

13. Transport

This section contains information on external and internal transportation of the product.

Transportation is the movement of the product by manual or technical means.

- Only use suitable and tested lifting gear and hoists for transportation!
- The product must only be transported using the means of transport specified by the manufacturer.
- Use the specified transport reinforcements.

Residual risks

	<p>Risk due to lifted loads! Standing under suspended loads is prohibited! Ensure that all components have sufficient load-bearing capacity! Observe all specifications of the respective manufacturer! The transport lugs must only be used for clamping down. Do not use the transport lugs for lifting!</p>
	<p>The transport is carried out by means of dangerous goods transport. The transportation of lithium-ion batteries "UN3536" is subject to the ADR regulations. A class 9 dangerous goods label must be affixed to all sides of the container during shipment. The current laws, regulations and standards must be observed when transporting the batteries (e. g. Dangerous Goods Transportation Act — GGBefG).</p>
	<p>Make sure that the parts and the outer packaging are in perfect condition.</p>
	<p>Make sure that</p> <ul style="list-style-type: none"> • all parts are firmly bolted connection, • the transport lugs and shackles have been properly attached, • you wear personal protective equipment.

Legal regulations

The off-site transportation of the product is carried out in accordance with the legal regulations of the country in which the product is transported off-site.

13.1. Safety instructions

- Transportation is carried out by a hazardous goods carrier.
- When transporting batteries, the applicable laws, regulations and standards (e. g. Dangerous Goods Transportation Act — GGBefG) must be complied with.
 All necessary authorizations and documents, such as a special permit and a dangerous goods

13.2. Change of location

driver's license (ADR certificate), must be available.

It must also be ensured that sufficiently tested lashing equipment is available.

- Upon receipt, check the delivery immediately for completeness and transport damage.
- Use personal protective equipment (depending on the boundary conditions) (minimum requirement: protective headgear and protective footwear).
- Disconnect the electrical connections before transport.
- Before lifting, check that the attachment points and lifting gear are correctly seated.
- The container should only be transported with a SoC of min. 25 % and max. 50 %.
- Observe the detailed lifting instructions for correct transportation.
- The load capacity must be dimensioned so that the mass of the product can be safely accommodated.
- The size of the transport surface must be dimensioned so that the product can be safely placed and secured on the transport surface.

13.2. Change of location

It is not intended to relocate the system after commissioning.

If a change of location is planned, consult FENECON GmbH beforehand.

The FENECON Industrial XL, fully equipped with battery packs, has a weight of approx. 32,000 kg.

13.3. Transportation process

Means of transportation

A means of transport that meets the following requirements is needed for safe off-site transportation:

- The load capacity must be dimensioned so that the mass of the product can be safely accommodated.
- The size of the transport platform must be dimensioned so that the product can be placed safely on the transport platform without falling.

Required aids

The following aids are required for safe off-site transportation:

- Loading and unloading: Use a crane. Only lift the fully-equipped Industrial XL container using the transport reinforcements provided.

- Transportation: only by motor vehicle for road transport.

13.3. Transportation process

Lifting instructions

- A crane with a minimum load capacity of 32 tons is required to transport a fully-equipped Industrial XL.
- When lifting the system, the lifting instructions specified by the manufacturer must be followed.
- Information on weight, center of gravity and dimensions are found in the dimensions and mass sections.

14. Dismantling and disposal

Residual risks:

	Misoperation Incorrect operation can lead to serious injury or death. Before switching off the individual components, observe the specifications and instructions in the operating/assembly instructions of the respective manufacturer.
	Incorrect operation can lead to material damage. Before switching off the system, make sure that there are no unauthorized persons in the danger zone.

14.1. Safety instructions

- The following suitable personal protective equipment must be worn for all work:
 - Protective footwear.
 - Protective gloves, cut-resistant if necessary.
 - Protective eyewear.
- The electrical energy storage system must only be dismantled by authorized qualified electricians.
- Dismantling work must only be carried out when the system has been taken out of operation.
- Before starting disassembly, all components to be removed must be secured against falling, tipping over or moving.
- Dismantling work must only be carried out when the system is shut down and only by service personnel.
- The existing attachment points must be used for the system parts to be transported.
- The dismantling instructions of the component manufacturers (Appendix, [Applicable documents](#)) must be observed.
- The slide-in battery modules are removed by service personnel and transported by hazardous goods transport.
- When transporting battery modules, the current laws, regulations and standards must be observed (e. g. Hazardous Goods Transportation Act — GGBeG).

14.2. Prerequisites

	Sharp and pointed edges Injuries to the body or limbs caused by sharp and pointed edges on parts of the system.
---	---

14.3. Disposal

- Always wear suitable protective equipment (cut-resistant protective gloves, protective footwear, protective eyewear) when working on the machine/electrical energy storage!
- The power supply to the system is interrupted and secured against being switched on again.

14.3. Disposal



- For the disposal of auxiliary and operating materials, observe the local regulations and information found on the safety data sheets.
- Please also observe the information in the individual operating instructions for the respective components.
- If in doubt about the disposal method, contact the manufacturer or the local waste disposal company/authorities.

After proper disassembly, the dismantled individual parts must be recycled:

- The electrical energy storage system must not be disposed of with normal household waste.
- Scrap metallic material residues.
- Have plastic elements recycled.
- Dispose of the remaining components sorted according to material properties.

Electrical waste, electronic components, lubricants and other auxiliary materials are subject to hazardous waste treatment and must only be disposed of by authorized specialist companies.

The following points must also be observed when disposing of the electrical energy storage system or its components as well as the operating and auxiliary materials:

- Comply with local national regulations.
- Observe company-specific specifications.
- Dispose of operating and auxiliary materials in accordance with the applicable safety data sheets.
- The packaging material must be disposed of in an environmentally friendly manner.

Batteries

- Do not expose the battery modules to high temperatures or direct sunlight.
- Do not expose the battery modules to high humidity or corrosive atmospheres.
- For special instructions on the disposal of used batteries, please contact the FENECON Service.

15. Declaration of Conformity



EU-Konformitätserklärung

Hersteller FENECON GmbH
Gewerbepark 6
94547 Iggensbach

Die alleinige Verantwortung für die Ausstellung dieser Konformitätserklärung trägt der Hersteller.

- **Produktbezeichnung:** FENECON Industrial XL
- **Beschreibung:** Stationäres Batterie-Energiespeichersystem (BESS) zur Speicherung und Abgabe elektrischer Energie, vorgesehen für den Anschluss an das öffentliche Niederspannungsnetz.

Der oben beschriebene Gegenstand der Erklärung erfüllt die einschlägigen Harmonisierungsvorschriften der Union, einschließlich derer zum Zeitpunkt dieser Erklärung gültigen Änderungen:

- Richtlinie 2014/35/EU (Niederspannungsrichtlinie)
- Richtlinie 2024/30/EU (EMV-Richtlinie)
- Richtlinie 2011/65/EU (RoHS-Richtlinie)
- Verordnung (EU) 2023/1542 (EU-Batterieverordnung)
 - Anmerkung: Der oben beschriebene Gegenstand der Erklärung erfüllt die zum Zeitpunkt des Inverkehrbringens geltenden, einschlägigen Anforderungen der Verordnung (EU) 2023/1542.

Nachweis der Konformität durch Einhaltung der folgenden Normen und Spezifikationen:

Richtlinie / Verordnung	Angewandte harmonisierte Normen / Technische Spezifikationen
Niederspannungsrichtlinie 2014/35/EU	EN IEC 61439-1:2021 (Niederspannungs-Schaltgerätekombinationen - Teil 1: Allgemeine Festlegungen) IEC 62933-5-2:2021 (Elektrische Energiespeichersysteme (EES) - Teil 5-2: Sicherheitsanforderungen an netzintegrierte EES-Systeme - Elektrochemische Systeme) EN IEC 62619:2022 (Sicherheitsanforderungen an sekundäre Lithiumzellen und -batterien für die Verwendung in industriellen Anwendungen) EN 62109-1:2010 (Sicherheit von Leistungsumrichtern zur Anwendung in photovoltaischen Energiesystemen - Teil 1: Allgemeine Anforderungen)

Seite 1 von 2

Stromspeichersysteme für die 100% Energiewende

15. Declaration of Conformity



	EN 62109-2:2011 (Sicherheit von Leistungsumrichtern zur Anwendung in photovoltaischen Energiesystemen - Teil 2: Besondere Anforderungen an Wechselrichter) EN 60204-1:2019 (Sicherheit von Maschinen – Elektrische Ausrüstung von Maschinen - Teil 1: Allgemeine Anforderungen) EN IEC 60664-1:2020 (Isolationskoordination für elektrische Betriebsmittel in Niederspannungsanlagen - Teil 1: Grundsätze, Anforderungen und Prüfungen) EN IEC 61010-1:2023 (Sicherheitsbestimmungen für elektrische Mess-, Steuer-, Regel- und Laborgeräte - Teil 1: Allgemeine Anforderungen)
EMV-Richtlinie 2014/30/EU	EN IEC 61000-6-2:2019 (Elektromagnetische Verträglichkeit (EMV) - Teil 6-2: Fachgrundnormen - Störfestigkeit für Industrieumgebungen) EN IEC 61000-6-4:2019 (Elektromagnetische Verträglichkeit (EMV) - Teil 6-4: Fachgrundnormen - Störaussendung für Industrieumgebungen)
RoHS-Richtlinie 2011/65/EU	EN IEC 63000:2018 (Technische Dokumentation zur Beurteilung von Elektro- und Elektronikgeräten hinsichtlich der Beschränkung gefährlicher Stoffe)

Weitere angewandte technische Spezifikationen zur Sicherstellung der Systemsicherheit und des nationalen Netzanschlusses:

- **System- und Anwendungssicherheit:**
 - **IEC 60730-1** (Automatische elektrische Regel- und Steuergeräte (Nachweis für das sicherheitszertifizierte Batterie-Management-System))
- **Nationale Netzanschlussregeln (DACH-Region):**
 - **Deutschland:** VDE-AR-N 4105:2018-11 und VDE-AR-N 4110:2018-11
 - **Österreich:** TOR Erzeuger Typ A & B und OVE-Richtlinie R 25:2020-03
 - **Schweiz:** VSE Branchenempfehlung NAVEEA-NE7 – CH 2020

Die in der Gemeinschaft ansässige Person, die für die Zusammenstellung der technischen Unterlagen bevollmächtigt ist, unterzeichnet für und im Namen von:

Name: Ludwig Asen, Gewerbepark 6, 94547 Iggensbach

Iggensbach, den 26.08.2025

Ort, Datum



ludwig asen
CTO

Seite 2 von 2

Stromspeichersysteme für die 100% Energiewende

16. Register

16.1. Applicable documents



- All supplier documentation can be accessed via the item bill of materials.

No.	Component	Manufacturer documentation
1	Product data sheet	https://docs.fenecon.de/pdfs/industrial/2025/en/MAR1327_FENECON_product_sheet_In-XL_EN_Web.pdf
2	Lifting instructions	https://docs.fenecon.de/pdfs/industrial/2025/en/INW-501-01_crane-lifting_inverter-rack.pdf https://docs.fenecon.de/pdfs/industrial/2025/en/IXL-217-01-02_crane-lifting_container.pdf
3	Transport instructions	https://docs.fenecon.de/pdfs/industrial/2025/de/INW-502-01_Niederspannen.pdf https://docs.fenecon.de/pdfs/industrial/2025/de/IXL-239-01-01_Niederspannen.pdf
4	Installation concept	https://docs.fenecon.de/pdfs/industrial/2025/en/IXL-351-01-00_installation_concept.pdf
5	Fire protection information	https://docs.fenecon.de/pdfs/industrial/2025/de/Brandschutzinformationen_FENECON_Industrial_XL_20250725_0V4.pdf
6	Supplement to the Ordinance on Installations for Handling Substances Hazardous to Water (AwSV)	https://docs.fenecon.de/pdfs/industrial/2025/de/Beiblatt_wassergefahrdende_Stoffe_AwSV_FENECON_Industrial_XL_20252802_0V1.pdf
7	Warranty conditions	https://docs.fenecon.de/pdfs/industrial/2025/en/V202509_EN_Garantiebedingungen_FENECON_Industrial_L-XL.pdf
8	Sound pressure	https://docs.fenecon.de/pdfs/industrial/2025/de/Infoblatt_Schall_Industrial-XL_rev03.pdf
9	Battery	cf. "Battery" Section of these Operating Instructions
10	Inverter KACO blueplanet gridsave 92.0 kVA	https://kaco-newenergy.com/index.php?eID=download&t=f&f=19743&token=480cf790aab1a3af6d22ec8aac872281e9ae3076 https://kaco-newenergy.com/products/blueplanet-gridsave-920-137-tl3-s
11	HYDAC Cooling system	https://www.hydac.com/shop/en-ch/4570230
12	Router MikroTik RB5009UG+S+IN	https://mikrotik.com/product/rb5009ug_s_in#fndtn-downloads

16.1. Applicable documents

No.	Component	Manufacturer documentation
13	Room air conditioning	Safety data sheet for auxiliary and operating materials: https://www.ittal.com/pdf-creator/variant/de-de/3188340 https://www.ittal.com/imf/none/3_11369/ 3188340_Anleitung_ndash_R_513A_DE https://www.ittal.com/imf/none/3_9033/ 3188340_Sicherheitsdatenblatt_K_auml_ltemittel_ndash_R_513A_DE
14	Block diagram	https://docs.fenecon.de/pdfs/industrial/2025/en/Industrial_XL_block_diagram_EN.pdf
15	Network diagram	https://docs.fenecon.de/pdfs/industrial/2025/en/Industrial_XL_network_plan_EN.pdf

Table 29. Applicable documents

16.2. List of Images

- Image 1. FENECON Industrial-XL—Type label
- Image 2. Type label on container without fire extinguishing system
- Image 3. Type label on the container with fire extinguishing system
- Image 4. Connection to FACP
- Image 5. Electrical energy storage system—Overview
- Image 6. Physical overview—front
- Image 7. Physical overview—rear
- Image 8. Battery container (open)
- Image 9. View—Control cabinet (open)
- Image 10. Steel construction—Battery containers
- Image 11. Control cabinet components (external)
- Image 12. Control cabinet components (internal)
- Image 13. AC connection area
- Image 14. DC connection area
- Image 15. Feedthroughs
- Image 16. Feedthroughs—Control cabinet
- Image 17. Cable glands—Inverters
- Image 18. Feedthroughs—Cooling system
- Image 19. Battery tower
- Image 20. Battery—front view
- Image 21. Battery—rear view
- Image 22. Cooling system distribution
- Image 23. Fire alarm system—Fire alarm control panel
- Image 24. Fire alarm system—Multi-detector sensor
- Image 25. Fire alarm system - switches and signaling devices
- Image 26. Lightning protection system
- Image 27. Inverter rack
- Image 28. Steel construction—Inverter rack
- Image 29. Inverter
- Image 30. Inverter—Junction box
- Image 31. Cable ladder
- Image 32. Equipotential bonding bar
- Image 33. Cooling system
- Image 34. Cable bridges
- Image 35. Standardized system configuration
- Image 36. Electrical energy storage system—rear view
- Image 37. Internet via fiber optics
- Image 38. Internet via ETH
- Image 39. FEMS Online Monitoring
- Image 40. Position of the air conditioning in the container

16.2. List of Images

[Image 41.](#) Cable glands on flange plate

[Image 42.](#) Connecting the room air conditioning

16.3. List of Tables

- Table 1. Version/revision
- Table 2. Symbol conventions
- Table 3. Symbol conventions — Signal words
- Table 4. SAFE method
- Table 5. Terms and abbreviations
- Table 6. Connection to FACP — Terminal assignment
- Table 7. Pictograms — Warning signs
- Table 8. Pictograms — Prohibition signs and mandatory signs
- Table 9. Physical overview
- Table 10. Battery container (open)
- Table 11. Control cabinet components (external)
- Table 12. Control cabinet components (internal)
- Table 13. DC connection area
- Table 14. Feedthroughs
- Table 15. Feedthroughs — Control cabinet
- Table 16. Cable glands — Inverters
- Table 17. Feedthroughs — Cooling system
- Table 18. Battery tower
- Table 19. Battery
- Table 20. Cooling system distribution
- Table 21. Fire alarm system
- Table 22. Lightning protection system
- Table 23. Inverter rack
- Table 24. Cooling system
- Table 25. Scope of delivery
- Table 26. Tools required
- Table 27. Fault display
- Table 28. Troubleshooting
- Table 29. Applicable documents