



FEMS — Creating an Installer Account

Version:2026.01.01

Table of Contents

1. Creating an Installer Account	1
2. Contact us	3

1. Creating an Installer Account

You can easily create an installer account for FENECON Online Monitoring yourself. To do this, please follow the steps below:

Step 1:

FEMS Login button on the FENECON website (<https://fenecon.de/>). Click on the *FEMS Login* button in the top right-hand corner of the page.



	 Alternative: Scan this QR code.
---	---

Step 2:

In the login window of the FENECON Online Monitoring (<https://portal.fenecon.de/login>), click on *Create account*.


1. Creating an Installer Account



The image shows the FENECON login page. At the top, the FENECON logo is displayed with the tagline "You are part of the energy journey". Below this is a "LOGIN" heading. There are two input fields: "E-Mail / User" and "Password". A "SIGN IN" button is located below the password field. At the bottom left, there are three links: "Reset Password", "Create account", and "Demo Access". A hand cursor is pointing at the "Create account" link.

Step 3:

Enter all the required data under *INSTALLER*.



The image shows the "Create account" form. The form has a blue header with the text "Create account" and a close button (X). Below the header, there are two tabs: "INSTALLER" (selected) and "USER". The "INSTALLER" tab contains several input fields, each marked with an asterisk (*): "Company name", "First name", "Last name", "Street", "Postal code", "City", "Country" (with a dropdown arrow), and "Phone number".

Step 4:

Check all entries, confirm the entry in the installer directory in addition to the privacy policy and the terms and conditions and then click on [arrow right from bracket] *CREATE*.

Step 5:

Log in to FENECON Online Monitoring with the e-mail and password you specified during the

registration process.

2. Contact us

For support, please contact:

FENECON GmbH
Gewerbepark 6
94547 Iggensbach

Phone — Service: +49 (0) 9903 6280 0

E-mail — Service: service@fenecon.de