




Legend	
	Network 99 (internet and standard connection to the customer network and power plant controller)
	Network 98 (optional network for separating between internet and customer network/power plant controller)
	Network 1 (internal)
	Network 10 (Battery tower 1 network)
	Network 20 (Battery tower 2 network)
	Network 30 (Battery tower 3 network)